

WORLDWIDE

**Z150P, LZ150P,
Z150Q, Z175G,
Z175H, Z200N,
LZ200N**

USA, CANADA

**Z150Z, LZ150Z,
VZ150Z, Z175Z,
VZ175Z, Z200Z,
LZ200Z**

**SUPPLEMENTARY
SERVICE MANUAL**

292067

68L-28197-ZA-AX

PREFACE

This Supplementary Service Manual has been prepared to introduce the modification and additional information for the Z200N and LZ200N. Also, new information for Z150P, LZ150P, Z150Q, Z175G and Z175H based on Z200N and LZ200N is included. For complete service information and procedures, it is necessary to add the following manual with the corresponding sections in this Supplementary Service Manual.

Z200N, LZ200N SERVICE MANUAL: 68F-28197-Z9-A1

CAUTION

USE UNLEADED STRAIGHT GASOLINE ONLY

- Gasoline containing lead can cause performance lose and engine damage.
- Do not use gasoline mixed with oil (premix).
- Use YAMALUBE 2 stroke outboard oil or another 2-stroke engine oil with a BIA-certified TC-W3 rate.

**Z150P, LZ150P, Z150Q,
Z175G, Z175H, Z200N, LZ200N
SUPPLEMENTARY SERVICE MANUAL
©2000 by Yamaha Motor Co., Ltd.
1st Edition, May 2000**

**All rights reserved. Any reprinting or
unauthorized use without the written
permission of Yamaha Motor Co., Ltd.
is expressly prohibited.**

Printed in Japan

HOW TO USE THIS MANUAL

MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and check operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings
Pitting/scratches → Replace.

To assist you in finding your way through this manual, the section title and major heading is given at the top of every page.

MODEL INDICATION

Multiple models are mentioned in this manual and their model indications are noted as follows.

Model name	Z150PETO	LZ150PETO	Z150QETO	Z175GETO	Z175HETO	Z200NETO	LZ200NETO
USA and Canada name	Z150TR	LZ150TR	VZ150TR	Z175TR	VZ175TR	Z200TR	LZ200TR
Indication	Z150PETO	LZ150PETO	Z150QETO	Z175GETO	Z175HETO	Z200NETO	LZ200NETO

ILLUSTRATIONS

The illustrations within this service manual represent all of the designated models.

CROSS REFERENCES

The cross references have been kept to a minimum. Cross references will direct you to the appropriate section or chapter.

IMPORTANT INFORMATION

In this Service Manual particularly important information is distinguished in the following ways.

 The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

WARNING

Failure to follow **WARNING** instructions could result in severe injury or death to the machine operator, a bystander, or a person inspecting or repairing the outboard motor.

CAUTION

A **CAUTION** indicates special precautions that must be taken to avoid damage to the outboard motor.

NOTE:


A **NOTE** provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

- ① The main points regarding removing/installing and disassembling/assembling procedures are shown in the exploded views.
- ② The numbers in the exploded views indicate the required sequence of the procedure and should be observed accordingly.
- ③ Symbols are used in the exploded views to indicate important aspects of the procedure. A list of meanings for these symbols is provided on the following page.
- ④ It is important to refer to the job instruction charts at the same time as the exploded views. These charts list the sequence that the procedures should be carried out in, as well as providing explanations on part names, quantities, dimensions and important points relating to each relevant task.

Example:

O-ring size 39.5 × 2.5 mm: inside diameter (D) × ring diameter (d)



- ⑤ In addition to tightening torques, the dimensions of the bolts or screws are also mentioned.

Example:

Bolt or screw size 10 × 25 mm : diameter (D) × length (L)



- ⑥ In addition to the exploded views and job instruction charts, this manual provides individual illustrations when further explanations are required to explain the relevant procedure.

LOWER UNIT (REGULAR ROTATION MODELS)

LOWER UNIT (REGULAR ROTATION MODELS)
REMOVING/INSTALLING THE LOWER UNIT

Order	Job/Part	Qty	Remarks
1	Spacer/star nose	1	
2	Propeller nut	1	
3	Washer	1	
4	Propeller	1	
5	Spacer	1	
6	Bolt	1	
7	Trim tub	1	
8	Bolt	1	(w/ th washer)
9	Bolt	6	(w/ th washer)
10	Lower unit	1	
11	Dowel pin	2	

For installation, reverse the removal procedure.

DRIVE SHAFT (REGULAR ROTATION MODELS)

REMOVING THE DRIVE SHAFT

Location:

- Pinion nut

Tools:

- Drive shaft holder YB-06701 / 90890-06520
- Pinion nut holder 90890-06505
- Pinion nut holder attachment 90890-06507

DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY

Remove:

- Needle bearing

Tools:

- Bearing/roll seal attachment YB-06196 / 90890-06610
- Driver rod YH-06071 / 90890-06652

DISASSEMBLING THE FORWARD GEAR ASSEMBLY

Remove:

- Open roller bearing

Tools:

- Bearing separator YB-06076 / 90890-06534

CAUTION:


























Do not reuse the bearing, always replace it with a new one.

Remove:

- Needle bearing

Tools:

- Slide hammer YB-06096
- Guide plate 90890-06501
- Guide plate stand 90890-06538
- Bearing puller 90890-06525
- Small universal claws 90890-06536

① GEN INFO 	② SPEC 	
③ INSP ADJ 	④ FUEL 	
⑤ POWR 	⑥ LOWR 	
⑦ BRKT 	⑧ ELEC 	
⑨ TRBL ANLS 	⑩ 	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	
⑰ 	⑱ 	
⑲ 	⑳ 	
㉑ 	㉒ 	
㉓  271	㉔  242	㉕  572

SYMBOLS

Symbols ① to ⑨ are designed as thumb-tabs to indicate the content of a chapter.

- ① General information
- ② Specifications
- ③ Periodic inspections and adjustments
- ④ Fuel system
- ⑤ Power unit
- ⑥ Lower unit
- ⑦ Bracket unit
- ⑧ Electrical systems
- ⑨ Trouble analysis

Symbols ⑩ to ⑮ indicate specific data.

- ⑩ Special tool
- ⑪ Specified liquid
- ⑫ Specified engine speed
- ⑬ Specified torque
- ⑭ Specified measurement
- ⑮ Specified electrical value
[Resistance (Ω), Voltage (V), Electric current (A)]

Symbol ⑯ to ⑲ in an exploded diagram indicate the grade of lubricant and the location of the lubrication point.

- ⑯ Apply Yamaha 2-stroke outboard motor oil
- ⑰ Apply water resistant grease
(Yamaha grease A, Yamaha marine grease)
- ⑱ Apply molybdenum disulfide grease
- ⑲ Apply corrosion resistant grease
(Yamaha grease D)

Symbols ⑳ to ㉕ in an exploded diagram indicate the grade of the sealing or locking agent and the location of the application point.

- ㉒ Apply Gasket Maker[®]
- ㉑ Apply Yamabond #4
(Yamaha bond number 4)
- ㉒ Apply silicon sealant
- ㉓ Apply LOCTITE[®] No. 271 (Red LOCTITE)
- ㉔ Apply LOCTITE[®] No. 242 (Blue LOCTITE)
- ㉕ Apply LOCTITE[®] No. 572

GENERAL INFORMATION

IDENTIFICATION	1
SERIAL NUMBER	1
STARTING SERIAL NUMBERS	1
SPECIAL TOOLS	2
MEASURING	2
REMOVING AND INSTALLING	5

SPECIFICATIONS

GENERAL SPECIFICATIONS	8
MAINTENANCE SPECIFICATIONS	14
POWER UNIT	14
LOWER UNIT	16
ELECTRICAL	16
POWER UNIT	20
LOWER UNIT	22
ELECTRICAL	22
DIMENSIONS	26
TIGHTENING TORQUES	31
SPECIFIED TORQUES	31
GENERAL TORQUES	33

PERIODIC INSPECTION AND ADJUSTMENT

MAINTENANCE INTERVAL CHART	34
FUEL SYSTEM	36
MEASURING THE FUEL PRESSURE (MEDIUM-PRESSURE FUEL LINE)	36
CHECKING THE FUEL PRESSURE (MECHANICAL FUEL PUMP)	37
CHECKING THE MECHANICAL FUEL PUMP OIL LEVEL	38
CHANGING THE MECHANICAL FUEL PUMP OIL	38

CONTROL SYSTEM	39
ADJUSTING THE THROTTLE POSITION SENSOR.....	39
ADJUSTING THE REMOTE CONTROL SHIFT CABLE (EXCEPT FOR Z150Q, Z175H/VZ150, VZ175)	41
ADJUSTING THE REMOTE CONTROL SHIFT CABLE (FOR Z150Q, Z175H/VZ150, VZ175).....	42
ADJUSTING THE CRANK POSITION SENSOR.....	42
 OIL INJECTION SYSTEM	 43
AIR BLEEDING THE OIL INJECTION SYSTEM.....	43
CHECKING THE ELECTRIC OIL PUMP.....	44
 POWER TRIM AND TILT SYSTEM	 44
CHECKING THE POWER TRIM AND TILT FLUID LEVEL	44
ADJUSTING THE TRIM SENSOR CAM.....	45
 LOWER UNIT	 46
CHECKING THE GEAR OIL LEVEL	46
CHANGING AND CHECKING THE GEAR OIL	46
CHECKING THE LOWER UNIT (FOR AIR LEAKS).....	47
 GENERAL	 48
CHECKING THE SPARK PLUGS.....	48
CHECKING THE IGNITION TIMING	49
MEASURING THE COMPRESSION PRESSURE	51
LUBRICATION POINTS.....	52

FUEL SYSTEM

MEDIUM-PRESSURE FUEL LINE	53
REDUCING THE FUEL PRESSURE (MEDIUM-PRESSURE FUEL LINE).....	53
CHECKING THE PRESSURE REGULATOR.....	53
 VAPOR SEPARATOR	 56
REMOVING/INSTALLING THE VAPOR SEPARATOR.....	56
 ELECTRIC FUEL PUMP	 58
DISASSEMBLING/ASSEMBLING THE ELECTRIC FUEL PUMP	58
 DRIVE BELT	 61
REMOVING/INSTALLING THE DRIVE BELT	61
 HIGH-PRESSURE FUEL LINE ASSEMBLY	 63
DISASSEMBLING/ASSEMBLING THE HIGH-PRESSURE FUEL LINE ASSEMBLY.....	63

MECHANICAL FUEL PUMP	66
DISASSEMBLING/ASSEMBLING THE MECHANICAL FUEL PUMP BODY	66

POWER UNIT

POWER UNIT	69
REMOVING/INSTALLING THE EXHAUST EXPANSION CHAMBER	69
INSTALLING THE APRON	71
REED VALVES	72
CHECKING THE REED VALVE ASSEMBLY	72
CRANKCASE	72
ASSEMBLING THE OIL SEAL HOUSING	72
CYLINDER BODY ASSEMBLY	73
DISASSEMBLING THE UPPER BEARING HOUSING	73
ASSEMBLING THE UPPER BEARING HOUSING	73

LOWER UNIT

LOWER UNIT (REGULAR ROTATION MODELS)	74
REMOVING/INSTALLING THE LOWER UNIT	74
PROPELLER SHAFT HOUSING ASSEMBLY (REGULAR ROTATION MODELS)	76
DISASSEMBLING THE PROPELLER SHAFT HOUSING	76
ASSEMBLING THE PROPELLER SHAFT HOUSING	77
DRIVE SHAFT (REGULAR ROTATION MODELS)	78
REMOVING/INSTALLING THE DRIVE SHAFT	78
REMOVING THE PINION	80
DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY	80
DISASSEMBLING THE FORWARD GEAR ASSEMBLY	80
ASSEMBLING THE FORWARD GEAR ASSEMBLY	81
ASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY	81
INSTALLING THE PINION	82
LOWER CASE ASSEMBLY (REGULAR ROTATION MODELS)	83
DISASSEMBLING/ASSEMBLING THE LOWER CASE ASSEMBLY	83
DISASSEMBLING THE LOWER CASE ASSEMBLY	84
ASSEMBLING THE LOWER CASE ASSEMBLY	84

LOWER UNIT (COUNTER ROTATION MODELS)	85
REMOVING/INSTALLING THE LOWER UNIT	85
PROPELLER SHAFT HOUSING ASSEMBLY (COUNTER ROTATION MODELS)	87
ASSEMBLING THE PROPELLER SHAFT HOUSING	87
DRIVE SHAFT (COUNTER ROTATION MODELS)	88
REMOVING/INSTALLING THE DRIVE SHAFT	88
REMOVING THE PINION	90
REMOVING THE REVERSE GEAR.....	90
DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY	90
DISASSEMBLING THE REVERSE GEAR ASSEMBLY.....	90
ASSEMBLING THE REVERSE GEAR ASSEMBLY.....	91
ASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY	92
INSTALLING THE REVERSE GEAR.....	92
INSTALLING THE PINION	93
LOWER CASE ASSEMBLY (COUNTER ROTATION MODELS)	93
ASSEMBLING THE LOWER CASE ASSEMBLY	93
SHIMMING (REGULAR ROTATION MODELS) (FOR USA AND CANADA)	94
SELECTING THE REVERSE GEAR SHIMS.....	95
SHIMMING (REGULAR ROTATION MODELS) (FOR WORLDWIDE)	97
SELECTING THE REVERSE GEAR SHIMS.....	98
BACKLASH (REGULAR ROTATION MODELS)	100
MEASURING THE FORWARD GEAR BACKLASH	100
MEASURING THE REVERSE GEAR BACKLASH.....	102
SHIMMING (COUNTER ROTATION MODELS) (FOR USA AND CANADA)	105
SELECTING THE FORWARD GEAR SHIMS	106
SHIMMING (COUNTER ROTATION MODELS) (FOR WORLDWIDE)	108
BACKLASH (COUNTER ROTATION MODELS)	109
MEASURING THE FORWARD GEAR BACKLASH	109
MEASURING THE REVERSE GEAR BACKLASH.....	110

BRACKET UNIT

CLAMP BRACKETS	113
REMOVING/INSTALLING THE CLAMP BRACKETS.....	113
TILT RAM ASSEMBLY AND GEAR PUMP UNIT.....	115
REMOVING/INSTALLING THE TILT RAM ASSEMBLY AND GEAR PUMP UNIT	115
REMOVING THE TILT RAM END SCREW	117
INSTALLING THE TILT RAM ASSEMBLY	117
TRIM RAM ASSEMBLIES AND FREE PISTON	118
REMOVING THE TRIM RAM END SCREWS	118
INSTALLING THE TRIM RAMS	118



ELECTRICAL SYSTEM

ELECTRICAL COMPONENTS ANALYSIS	120
DIGITAL CIRCUIT TESTER.....	120
MEASURING THE PEAK VOLTAGE.....	120
PEAK VOLTAGE ADAPTOR.....	120
MEASURING A LOW RESISTANCE.....	121
IGNITION CONTROL SYSTEM	122
MEASURING THE THROTTLE POSITION SENSOR OUTPUT VOLTAGE.....	122
FUEL CONTROL SYSTEM.....	123
CHECKING THE FUEL PRESSURE SENSOR.....	123
CHARGING SYSTEM.....	124
MEASURING THE LIGHTING COIL OUTPUT PEAK VOLTAGE	124
POWER TRIM AND TILT SYSTEM	124
MEASURING THE TRIM SENSOR RESISTANCE.....	124

TROUBLE ANALYSIS

SELF-DIAGNOSIS	125
DIAGNOSIS CODE INDICATION.....	125
DIAGNOSIS THE ELECTRONIC CONTROL SYSTEM	125
YAMAHA DIAGNOSTIC SYSTEM	127
CONNECTING THE COMPUTER TO THE OUTBOARD	127
YAMAHA DIAGNOSTIC SYSTEM FUNCTION.....	128

WIRING DIAGRAM



**IDENTIFICATION
SERIAL NUMBER**

The outboard motor's serial number is stamped on a label which is attached to the port side of the clamp bracket.


NOTE: _____
If the serial number label is removed, "VOID" marks will be appear on the label.

- ① Model name
- ② Approved model code
- ③ Transom height
- ④ Serial number

STARTING SERIAL NUMBERS

The starting serial number blocks are as follows:

Worldwide	Model name		Approved model code	Starting serial number
	USA	Canada		
Z150PETO	Z150TR	—	6G4	L: 800101 -
		Z150TR		X: 850101 -
LZ150PETO	LZ150TR	—	6K0	X: 800101 -
Z150QETO	VZ150TR	VZ150TR	6J9	L: 800101 -
Z175GETO	Z175TR	—	6G5	X: 800101 -
Z175HETO	VZ175TR	VZ175TR	62H	L: 800101 -
Z200NETO	Z200TR	—	6G6	L: 150101 -
		Z200TR		X: 100101 -
LZ200NETO	LZ200TR	—	6K1	X: 100101 -



SPECIAL TOOLS


Using the correct special tools recommended by Yamaha, will aid the work and enable accurate assembly and tune-up. Improvising and using improper tools can damage the equipment.

NOTE:


- For USA and Canada, use part numbers that start with "J-", "YB-", "YM-", "YS-", "YU-", "YW-" or "YX-".
- For worldwide, use part numbers that start with "90890-".

MEASURING

- ① Tachometer
P/N. YU-08036-B (a)
90890-06760 (b)
- ② Fuel pressure gauge
P/N. YB-06766 (a)
90890-06786 (b)
- ③ Pressure/vacuum tester
P/N. YB-35956-A
90890-06756
- ④ Leakage tester
P/N. 90890-06762
- ⑤ Timing light
P/N. YM-33277-A..... (a)
90890-03141 (b)
- ⑥ Compression gauge
P/N. YU-33223-1..... (a)
90890-03160 (b)
- ⑦ Pinion height gauge
P/N. YB-34432-7, YB-34432-11 (a)
90890-06702 (b)
- ⑧ Shimming gauge
P/N. YB-34446-1, YB-34446-3,
YB-34446-4, YB-34446-7,
YB-34446-8
- ⑨ Shimming gauge
P/N. YB-34468-1A
- ⑩ Shimming plate
P/N. 90890-06701
- ⑪ Digital caliper
P/N. 90890-06704
- ⑫ Shift rod wrench
P/N. YB-06052 (a)
90890-06052 (b)



- ⑬ Magnetic base
P/N. YU-34481
90890-06705
- ⑭ Magnetic base attaching plate
P/N. YB-07003
90890-07003
- ⑮ Backlash indicator
P/N. YB-06265
90890-06706
- ⑯ Dial gauge set
P/N. YU-03097
90890-01252
- ⑰ Hydraulic pressure gauge
P/N. 90890-06776
- ⑱ Up-relief valve attachment
P/N. 90890-06773
Down-relief valve attachment
P/N. 90890-06774
- ⑲ Digital tester
P/N. YU-34899-A ①
90890-06752 ②
- ⑳ Peak voltage adapter
P/N. YU-39991 ①
90890-03172 ②
- ㉑ Spark gap tester
P/N. YM-34487 ①
90890-06754 ②
- ㉒ Test harness
P/N. YB-06757, YB-06767,
YB-06769, YB-06779,
YB-06787, YB-06788
90890-06757, 90890-06767,
90890-06769, 90890-06779,
90890-06787, 90890-06788
- ㉓ Diagnostic indicator
P/N. YB-06444
90890-06765



② Yamaha Diagnostic System
P/N. 68F-85300-00

Check the engine condition by using a personal computer when it is connected to the Electronic Control Unit (ECU).

Diagnosis:

Indicates the name of a failed part.

Diagnosis Record:

Displays the name of the part whose diagnosis is detected, along with the engine running total hours.

Engine Monitor:

Indicates information on the sensors and switches by converting it to each value while the engine is running.

Stationary Test:

Checks operation sound and ignition sparks by activating the electric fuel pump, electric oil pump, injector and spark plug while the engine is stopped.

Active Test:

Checks the engine for operation through any change in its speed by stopping the operation of the spark plug on each cylinder while the engine is in the neutral position.

Data Logger:

Indicates in numeric values the engine speed, throttle opening voltage, oxygen density sensor voltage, water temperature sensor voltage and fuel pressure sensor voltage that occurred within 13 minutes.


ECM No.:

Displays the ECM identification number.

NOTE: _____


To use any of these functions a personal computer, connection cables, adapter and communication software are required.

The personal computer should be compatible with Windows® 95/98, equipped with a CD-ROM and the RS232C terminal.




REMOVING AND INSTALLING

- ① Flywheel magnet assembly holder
 P/N. YB-06139 (a)
 90890-06522 (b)
- ② Universal puller
 P/N. YB-06117 (a)
 90890-06521 (b)
- ③ Bearing/oil seal attachment
 P/N. YB-06205-1 (a)
 90890-06663 (b)
- ④ Piston ring compressor
 P/N. YU-33294 (a)
 90890-06530 (b)
- ⑤ Bearing separator
 P/N. YB-06219 (a)
 90890-06534 (b)
- ⑥ Guide plate stand
 P/N. 90890-06538
- ⑦ Guide plate
 P/N. 90890-06501
- ⑧ Bearing puller
 P/N. 90890-06535
- ⑨ Small universal claws
 P/N. 90890-06536
- ⑩ Ring nut wrench
 P/N. YB-34447 (a)
 90890-06512 (b)
- ⑪ Ring nut wrench extension
 P/N. 90890-06513



- ⑫ Propeller shaft housing puller
P/N. YB-06207 ①
90890-06502 ②
- ⑬ Center bolt
P/N. 90890-06504
- ⑭ Slide hammer
P/N. YB-06096
90890-06531
- ⑮ Drive shaft holder
P/N. YB-06201
90890-06520
- ⑯ Pinion nut holder
P/N. 90890-06505
- ⑰ Pinion nut holder attachment
P/N. 90890-06507
- ⑱ Bearing puller
P/N. YB-06029, YB-06430
90890-06523
- ⑲ Large universal claws
P/N. 90890-06532
- ⑳ Driver rod
P/N. YB-06071, YB-06229
90890-06604, 90890-06605,
90890-06606, 90890-06652
- ㉑ Bearing/oil seal depth plate
P/N. 90890-06603
- ㉒ Bearing/oil seal attachment
P/N. YB-06194, YB-06196, YB-06246
- ㉓ Bearing/oil seal attachment
P/N. YB-06195, YB-06258,
YB-06348, YB-06434
- ㉔ Bearing/oil seal attachment
P/N. YB-06261
- ㉕ Bearing/oil seal attachment
P/N. YB-06336, YB-41446
- ㉖ Bearing/oil seal attachment
P/N. 90890-06610, 90890-06612,
90890-06633, 90890-06636,
90890-06653, 90890-06654,
90890-06655
- ㉗ Bearing/oil seal attachment
P/N. 90890-06619, 90890-06622
- ㉘ Bearing/oil seal attachment
P/N. 90890-06629, 90890-06630



- ②⑨ Bearing/oil seal attachment
P/N. 90890-06635
- ③⑩ Bearing/oil seal attachment
P/N. 90890-06640, 90890-06660,
90890-06661, 90890-06662
- ③① Slide hammer attachment
P/N. YB-06335
90890-06514
- ③② End screw wrench
P/N. YB-06175, YX-06765
90890-06548
- ③③ Universal holder
P/N. YU-01235
90890-01235
- ③④ Sheave holder
P/N. YS-1880-A
90890-01701
- ③⑤ Universal puller
P/N. YB-06540
90890-06540

GENERAL SPECIFICATIONS

Item			Unit	Model		
	Worldwide			Z150PETO	LZ150PETO	Z150QETO
	USA			Z150TR	LZ150TR	VZ150TR
	Canada			Z150TR	—	VZ150TR
DIMENSION						
Overall length		mm (in)	792 (31.2)			
Overall width		mm (in)	554 (21.8)			
Overall height		mm (in)	1,655 (65.2)	—	1,693 (66.7)	
(L)		mm (in)	1,782 (70.2)			
(X)		mm (in)	—			
Boat transom height		mm (in)	508 (20.0)	—	508 (20.0)	
(L)		mm (in)	635 (25.0)			
(X)		mm (in)	—			
WEIGHT						
(with aluminum propeller)		kg (lb)	214 (472)	—	215 (474)	
(L)		kg (lb)	218 (481)			
(X)		kg (lb)	—			
(with stainless steel propeller)		kg (lb)	216 (476)	—	217 (478)	
(L)		kg (lb)	222 (489)			
(X)		kg (lb)	—			
PERFORMANCE						
Maximum output (ISO)		kW (hp) @ 5,000 r/min	110.3 (150)			
Full throttle operating range		r/min	4,500 - 5,500			
Maximum fuel consumption		L (US gal, Imp gal)/hr @ 5,500 r/min	55.0 (14.5, 12.1)			
POWER UNIT						
Type			2 stroke - V			
Number of cylinders			6			
Displacement		cm ³ (cu. in)	2,596 (158.4)			
Bore × stroke		mm (in)	90.0 × 68.0 (3.54 × 2.68)			
Compression ratio			Cylinders #1 - #4: 6.7 Cylinders #5 - #6: 6.4			
Compression pressure		kPa (kgf/cm ² , psi)	650 (6.5, 92)			
Fuel system			Electronic fuel injection			
Fuel injection system			Sequential injection			
Intake system			Reed valve			
Induction system			Loop charge			
Starting system			Electric			

* Measuring conditions:

Ambient temperature 20 °C (68 °F), wide open throttle, plugs disconnected from all cylinders.

The figures are for reference only.



Item	Worldwide USA Canada		Unit	Model		
				Z150PETO	LZ150PETO	Z150QETO
				Z150TR	LZ150TR	VZ150TR
				Z150TR	—	VZ150TR
Ignition control system Alternator output Spark plugs Cooling system Exhaust system Lubrication system			V - A	Microcomputer 12 - 45 BKR6ES-11 Water Through propeller boss Oil injection		
FUEL AND OIL Fuel type Fuel rating Engine oil type Engine oil capacity (engine oil tank) (sub-oil tank) Gear oil type Gear oil total quantity			*PON RON L (US qt, Imp qt) L (US qt, Imp qt) cm ³ (US oz, Imp oz)	Unleaded regular gasoline 86 91 YAMALUBE 2-stroke outboard engine oil 0.9 (0.95, 0.79) 10.5 (11.1, 9.2) Hypoid gear oil SAE 90 980 (33.1, 34.5) 870 (29.4, 30.6) 980 (33.1, 34.5)		
BRACKET Trim angle (at 12° boat transom) Tilt-up angle Steering angle			Degree Degree Degree	-4 - 16 70 32 + 32		
DRIVE UNIT Gear shift positions Gear ratio Reduction gear type Clutch type Propeller shaft type Propeller direction (rear view) Propeller mark				F-N-R 1.86 (26/14) 2.00 (28/14) Spiral bevel gear Dog clutch Spline Clockwise Counter-clockwise Clockwise M ML M		
ELECTRICAL Battery capacity Minimum cold cranking performance			Ah (kC) A	100 (360) 512		

* PON: Pump Octane Number (Research octane + Motor octane)/2
RON: Research Octane Number



Item			Model	
	Worldwide	Unit	Z175GETO	Z175HETO
	USA		Z175TR	VZ175TR
	Canada		—	VZ175TR
DIMENSION				
Overall length		mm (in)	792 (31.2)	
Overall width		mm (in)	554 (21.8)	
Overall height				
(L)		mm (in)	—	1,693 (66.7)
(X)		mm (in)	1,782 (70.2)	—
Boat transom height				
(L)		mm (in)	—	508 (20.0)
(X)		mm (in)	635 (25.0)	—
WEIGHT				
(with aluminum propeller)				
(L)		kg (lb)	—	215 (474)
(X)		kg (lb)	218 (481)	—
(with stainless steel propeller)				
(L)		kg (lb)	—	217 (478)
(X)		kg (lb)	222 (489)	—
PERFORMANCE				
Maximum output (ISO)		kW (hp) @ 5,000 r/min	128.7 (175)	
Full throttle operating range		r/min	4,500 - 5,500	
Maximum fuel consumption		L (US gal, Imp gal)/hr @ 5,500 r/min	64.0 (16.9, 14.1)	
POWER UNIT				
Type			2 stroke - V	
Number of cylinders			6	
Displacement		cm ³ (cu. in)	2,596 (158.4)	
Bore × stroke		mm (in)	90.0 × 68.0 (3.54 × 2.68)	
Compression ratio			Cylinders #1 - #4: 6.5 Cylinders #5 - #6: 6.1	
Compression pressure*		kPa (kgf/cm ² , psi)	650 (6.5, 92)	
*Fuel system			Electronic fuel injection	
Fuel injection system			Sequential injection	
Intake system			Reed valve	
Induction system			Loop charge	
Starting system			Electric	
Ignition control system			Microcomputer	
Alternator output		V - A	12 - 45	

* Measuring conditions:
 Ambient temperature 20 °C (68 °F), wide open throttle, plugs disconnected from all cylinders.
 The figures are for reference only.



Item			Unit	Model	
	Worldwide			Z175GETO	Z175HETO
	USA			Z175TR	VZ175TR
	Canada			—	VZ175TR
Spark plugs				BKR7ES-11	
Cooling system				Water	
Exhaust system				Through propeller boss	
Lubrication system				Oil injection	
FUEL AND OIL					
Fuel type				Unleaded regular gasoline	
Fuel rating			*PON	86	
			RON	91	
Engine oil type				YAMALUBE 2-stroke outboard engine oil	
Engine oil capacity (engine oil tank)			L (US qt, Imp qt)	0.9 (0.95, 0.79)	
(sub-oil tank)			L (US qt, Imp qt)	10.5 (11.1, 9.2)	
Gear oil type				Hypoid gear oil SAE 90	
Gear oil total quantity			cm ³ (US oz, Imp oz)	980 (33.1, 34.5)	
BRACKET					
Trim angle (at 12° boat transom)			Degree	-4 - 16	
Tilt-up angle			Degree	70	
Steering angle			Degree	32 + 32	
DRIVE UNIT					
Gear shift positions				F-N-R	
Gear ratio				1.86 (26/14)	
Reduction gear type				Spiral bevel gear	
Clutch type				Dog clutch	
Propeller shaft type				Spline	
Propeller direction (rear view)				Clockwise	
Propeller mark				M	
ELECTRICAL					
Battery capacity			Ah (kC)	100 (360)	
Minimum cold cranking performance			A	512	

* PON: Pump Octane Number (Research octane + Motor octane)/2

RON: Research Octane Number



Item	Worldwide		Unit	Model	
	USA			Z200NETO	LZ200NETO
	Canada			Z200TR	LZ200TR
				Z200TR	—
DIMENSION					
Overall length			mm (in)	792 (31.2)	
Overall width			mm (in)	554 (21.8)	
Overall height					
(L)			mm (in)	1,655 (65.2)	—
(X)			mm (in)	1,782 (70.2)	
Boat transom height					
(L)			mm (in)	508 (20.0)	—
(X)			mm (in)	635 (25.0)	
WEIGHT					
(with aluminum propeller)					
(L)			kg (lb)	214 (472)	—
(X)			kg (lb)	218 (481)	
(with stainless steel propeller)					
(L)			kg (lb)	216 (476)	—
(X)			kg (lb)	222 (489)	
PERFORMANCE					
Maximum output (ISO)			kW (hp) @ 5,000 r/min	147.1 (200)	
Full throttle operating range			r/min	4,500 - 5,500	
Maximum fuel consumption			L (US gal, Imp gal)/hr @ 5,500 r/min	68.0 (18.0, 15.0)	
POWER UNIT					
Type				2 stroke - V	
Number of cylinders				6	
Displacement			cm ³ (cu. in)	2,596 (158.4)	
Bore × stroke			mm (in)	90.0 × 68.0 (3.54 × 2.68)	
Compression ratio				Cylinders #1 - #4: 6.3 Cylinders #5 - #6: 6.0	
Compression pressure*			kPa (kgf/cm ² , psi)	650 (6.5, 92)	
Fuel system				Electronic fuel injection	
Fuel injection system				Sequential injection	
Intake system				Reed valve	
Induction system				Loop charge	
Starting system				Electric	
Ignition control system				Microcomputer	
Alternator output			V - A	12 - 45	






* Measuring conditions:
 Ambient temperature 20 °C (68 °F), wide open throttle, plugs disconnected from all cylinders.
 The figures are for reference only.



Item	Unit		Model	
			Z200NETO	LZ200NETO
			Z200TR	LZ200TR
			Z200TR	—
Spark plugs			BKR7ES-11	
Cooling system			Water	
Exhaust system			Through propeller boss	
Lubrication system			Oil injection	
FUEL AND OIL				
Fuel type			Unleaded regular gasoline	
Fuel rating		*PON RON	86 91	
Engine oil type			2-stroke outboard engine oil	
Engine oil capacity (engine oil tank)	L (US qt, Imp qt)		0.9 (0.95, 0.79)	
(sub-oil tank)	L (US qt, Imp qt)		10.5 (11.1, 9.2)	
Gear oil type			Hypoid gear oil SAE 90	
Gear oil total quantity	cm ³ (US oz, Imp oz)		980 (33.1, 34.5)	870 (29.4, 30.6)
BRACKET				
Trim angle (at 12° boat transom)	Degree		-4 - 16	
Tilt-up angle	Degree		70	
Steering angle	Degree		32 + 32	
DRIVE UNIT				
Gear shift positions			F-N-R	
Gear ratio			1.86 (26/14)	
Reduction gear type			Spiral bevel gear	
Clutch type			Dog clutch	
Propeller shaft type			Spline	
Propeller direction (rear view)			Clockwise	Counterclockwise
Propeller mark			M	ML
ELECTRICAL				
Battery capacity	Ah (kC)		100 (360)	
Minimum cold cranking performance	A		512	

* PON: Pump Octane Number (Research octane + Motor octane)/2
 RON: Research Octane Number

**MAINTENANCE SPECIFICATIONS
POWER UNIT**

Item	Unit	Model					
		Worldwide	Z150PETO	LZ150PETO	Z150QETO	Z175GETO	Z175HETO
		USA	Z150TR	LZ150TR	VZ150TR	Z175TR	VZ175TR
		Canada	Z150TR	—	VZ150TR	—	VZ175TR
CYLINDER HEADS Warpage limit  (lines indicate straightedge position)		mm (in)	0.1 (0.004)				
CYLINDERS Bore size Wear limit Taper limit Out-of-round limit 		mm (in)	90.00 - 90.02 (3.543 - 3.544)				
PISTONS Piston diameter (D) Measuring point (H) Piston-to-cylinder clearance <Limit> Oversize piston diameter 1st 2nd 		mm (in)	89.845 - 89.869 (3.5372 - 3.5381)				
PISTON RINGS Type (B) (T) End gap (installed) <Limit> Side clearance 		mm (in)	Keystone 2.0 (0.079) 2.8 (0.110) 0.30 - 0.40 (0.012 - 0.016) 0.60 (0.024) 0.02 - 0.06 (0.001 - 0.002)				
CRANKSHAFT Runout limit 		mm (in)	0.05 (0.002)				



Item	<table border="1"> <tr><td>Worldwide</td></tr> <tr><td>USA</td></tr> <tr><td>Canada</td></tr> </table>		Worldwide	USA	Canada	Unit	Model				
			Worldwide								
			USA								
			Canada								
Z150PETO	LZ150PETO	Z150QETO	Z175GETO	Z175HETO							
Z150TR	LZ150TR	VZ150TR	Z175TR	VZ175TR							
Z150TR	—	VZ150TR	—	VZ175TR							
CONNECTING RODS											
Small-end axial play limit (F)		mm (in)	2.0 (0.08)								
Big-end side clearance (E)		mm (in)	0.12 - 0.26 (0.005 - 0.010)								
OIL INJECTION PUMP											
ID mark			68H00		68L00						
Bleeding			Screw type								
REED VALVES											
Reed valve stopper height (a)		mm (in)	8.1 ± 0.30 (0.32 ± 0.01)								
Warpage limit (b)		mm (in)	0.2 (0.008)								
THERMOSTATS											
Opening temperature			°C (°F)	48 - 52 (118 - 126)							
Full-open temperature			°C (°F)	60 (140)							
Valve open lower limit			mm (in)	3 (0.12)							
ENGINE SPEED											
Idling speed			r/min	700 ± 30							



LOWER UNIT

Item	Worldwide		Unit	Model				
	USA			Z150PETO	LZ150PETO	Z150QETO	Z175GETO	Z175HETO
	Canada			Z150TR	—	VZ150TR	—	VZ175TR
GEAR BACKLASH								
Pinion - forward gear	mm (in)	0.25 - 0.46 (0.010 - 0.018)	0.21 - 0.43 (0.008 - 0.017)	0.72 - 1.01 (0.028 - 0.040)	0.25 - 0.46 (0.010 - 0.018)			
Pinion - reverse gear	mm (in)	0.74 - 1.29 (0.029 - 0.051)	0.97 - 1.29 (0.038 - 0.051)	0.79 - 1.39 (0.031 - 0.055)	0.74 - 1.29 (0.029 - 0.051)			
Pinion shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50						
Forward gear shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50						
Reverse gear shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50						

ELECTRICAL

Item	Worldwide		Unit	Model				
	USA			Z150PETO	LZ150PETO	Z150QETO	Z175GETO	Z175HETO
	Canada			Z150TR	—	VZ150TR	—	VZ175TR
IGNITION SYSTEM								
Ignition timing								
#1 cylinder								
(L) @ idling speed (700 r/min)	Degree	BTDC 3	—	BTDC 3	—	BTDC 3		
(X) @ idling speed (700 r/min)	Degree	BTDC 4	BTDC 4	—	BTDC 3	—		
@ 5,500 r/min	Degree	BTDC 17	BTDC 17	BTDC 17	BTDC 20	BTDC 20		
#2 cylinder								
(L) @ idling speed (700 r/min)	Degree	BTDC 3	—	BTDC 3	—	BTDC 3		
(X) @ idling speed (700 r/min)	Degree	BTDC 4	BTDC 4	—	BTDC 3	—		
@ 5,500 r/min	Degree	BTDC 15	BTDC 15	BTDC 17	BTDC 20	BTDC 20		
Fuse 1	V-A	12-80						
Fuse 2	V-A	12-30						
Fuse 3	V-A	12-20						
Control unit (B/O, B/Y, B/L, B/Br, B/G, B/W - R/Y)								
Output peak voltage lower limit								
@ cranking 1*	V	—						
@ cranking 2*	V	140						
@ 1,500 r/min	V	205						
@ 3,500 r/min	V	220						

* Cranking 1: unloaded
 Cranking 2: loaded



Item	Worldwide USA Canada	Unit	Model							
			Z150PETO	LZ150PETO	Z150QETO	Z175GETO	Z175HETO			
			Z150TR	LZ150TR	VZ150TR	Z175TR	VZ175TR			
			Z150TR	—	VZ150TR	—	VZ175TR			
Pulser coil (W/R, W/Y, W/G, W/B, W/L, W/Br - B) Output peak voltage lower limit										
@ cranking 1*	V			5.0						
@ cranking 2*	V			5.0						
@ 1,500 r/min	V			20						
@ 3,500 r/min	V			35						
IGNITION CONTROL SYSTEM										
Crank position sensor (G/L) Crank-position-sensor-to-flywheel gap		mm (in)								1.0 ± 0.5 (0.04 ± 0.02)
Output peak voltage lower limit										
@ cranking 1*	V									4.5
@ cranking 2*	V									4.0
@ 1,500 r/min	V									13
@ 3,500 r/min	V									20
Engine cooling water temperature sensor										
Resistance (B/Y - B/Y)										/
@ 5°C (41°F)	kΩ									128
@ 20°C (68°F)	kΩ									54 - 69
@ 100°C (212°F)	kΩ									3.02 - 3.48
Throttle position sensor										
Input voltage (O - R)	V									4.75 - 5.25
Output voltage (P - O)	V									0.48 - 5.25
Thermo switch (P - B)										
OFF → ON	°C (°F)									84 - 90 (183 - 194)
ON → OFF	°C (°F)									60 - 74 (140 - 165)
FUEL CONTROL SYSTEM										
Oxygen density sensor										
* Heater resistance (R/W - B)	Ω									2 - 100
Output voltage (Gy - B/W)	V									0.0 - 1.0
Atmospheric pressure sensor										
Output voltage (at 101.32 kPa) (P - B)	V									3.2 - 4.6
Intake air temperature sensor										
Resistance (B/Y - B/Y)	kΩ									1.5 - 4.0

* Cranking 1: unloaded
Cranking 2: loaded



Item	Worldwide USA Canada	Unit	Model				
			Z150PETO	LZ150PETO	Z150QETO	Z175GETO	Z175HETO
			Z150TR	LZ150TR	VZ150TR	Z175TR	VZ175TR
			Z150TR	—	VZ150TR	—	VZ175TR
Injector driver (O/R – Pu/R, O/B – Pu/B, O/Y – Pu/Y, O/G – Pu/G, O/L – Pu/L, O/W – Pu/W)							
Output peak voltage lower limit							
@ cranking 1*		V			65		
@ cranking 2*		V			60		
@ 1,500 r/min		V			65		
@ 3,500 r/min		V			65		
Fuel pressure sensor							
Output voltage (P – B)		V			2.8 - 3.2		
STARTER MOTOR							
Type					Sliding gear		
Output		kW			1.4		
Cranking time limit		Second			30		
Brushes							
Standard length		mm (in)			15.5 (0.61)		
Wear limit		mm (in)			9.5 (0.37)		
Commutator							
Standard diameter		mm (in)			29.0 (1.14)		
Wear limit		mm (in)			28.0 (1.10)		
Mica							
Standard undercut		mm (in)			0.5 - 0.8 (0.02 - 0.03)		
Wear limit		mm (in)			0.2 (0.01)		
CHARGING SYSTEM							
Rectifier/regulator (R – B)							
Output peak voltage lower limit							
@ cranking 1*		V			—		
@ cranking 2*		V			7.5		
@ 1,500 r/min		V			12.7		
@ 3,500 r/min		V			12.7		
Lighting coil (G – G)							
Output peak voltage lower limit							
@ cranking (unloaded)		V			5.5		
@ 1,500 r/min (unloaded)		V			37		
@ 3,500 r/min (unloaded)		V			86		






* Cranking 1: unloaded
Cranking 2: loaded



Item			Unit	Model				
	Worldwide			Z150PETO	LZ150PETO	Z150QETO	Z175GETO	Z175HETO
	USA			Z150TR	LZ150TR	VZ150TR	Z175TR	VZ175TR
	Canada			Z150TR	—	VZ150TR	—	VZ175TR
OIL FEED PUMP CONTROL SYSTEM								
Oil level sensor (engine oil tank)								
Float position ① "OFF"			mm (in)	3 - 6 (0.12 - 0.24)				
Float position ② "ON"			mm (in)	33 - 36 (1.30 - 1.42)				
Float position ③ "ON"			mm (in)	53 - 56 (2.09 - 2.20)				
Oil level switch (sub-oil tank)								
Float position ④ "ON"			mm (in)	150 - 153 (5.91 - 6.02)				
POWER TRIM AND TILT SYSTEM								
Trim sensor								
Setting resistance			Ω	11 ± 7				
Resistance (P - B)			Ω	10 - 309				
POWER TRIM AND TILT MOTOR								
Fluid type				ATF Dexron II				
Brushes								
Standard length			mm (in)	9.8 (0.39)				
Wear limit			mm (in)	4.8 (0.19)				
Commutator								
Standard diameter			mm (in)	22.0 (0.87)				
Wear limit			mm (in)	21.0 (0.83)				
Mica								
Standard undercut			mm (in)	1.35 (0.05)				
Wear limit			mm (in)	0.85 (0.03)				



POWER UNIT

Item	<table border="1"> <tr><td>Worldwide</td></tr> <tr><td>USA</td></tr> <tr><td>Canada</td></tr> </table>		Worldwide	USA	Canada	Unit	Model	
			Worldwide					
			USA					
			Canada					
Z200NETO	LZ200NETO							
Z200TR	LZ200TR							
Z200TR	—							
CYLINDER HEADS Warpage limit  (lines indicate straightedge position)			mm (in)	0.1 (0.004)				
CYLINDERS Bore size Wear limit Taper limit Out-of-round limit 			mm (in) mm (in) mm (in) mm (in)	90.00 - 90.02 (3.543 - 3.544) 90.1 (3.55) 0.08 (0.003) 0.05 (0.002)				
PISTONS Piston diameter (D) Measuring point (H) Piston-to-cylinder clearance <Limit> Oversize piston diameter 1st 2nd 			mm (in) mm (in) mm (in) mm (in) mm (in) mm (in)	89.845 - 89.869 (3.5372 - 3.5381) 10 (0.4) 0.150 - 0.156 (0.0059 - 0.0061) 0.206 (0.0081) 90.11 (3.548) 90.36 (3.557)				
PISTON RINGS Type (B) (T) End gap (installed) <Limit> Side clearance 			mm (in) mm (in) mm (in) mm (in) mm (in)	Keystone 2.0 (0.079) 2.8 (0.110) 0.30 - 0.40 (0.012 - 0.016) 0.60 (0.024) 0.02 - 0.06 (0.001 - 0.002)				
CRANKSHAFT Runout limit 			mm (in)	0.05 (0.002)				



Item	<table border="1"> <tr><td>Worldwide</td></tr> <tr><td>USA</td></tr> <tr><td>Canada</td></tr> </table>		Worldwide	USA	Canada	Unit	Model	
			Worldwide					
			USA					
			Canada					
Z200NETO	LZ200NETO							
Z200TR	LZ200TR							
Z200TR	—							
CONNECTING RODS								
Small-end axial play limit (F)		mm (in)	2.0 (0.08)					
Big-end side clearance (E)		mm (in)	0.12 - 0.26 (0.005 - 0.010)					
OIL INJECTION PUMP								
ID mark			68F00					
Bleeding			Screw type					
REED VALVES								
Reed valve stopper height (a)		mm (in)	9.0 ± 0.35 (0.35 ± 0.01)					
Warpage limit (b)		mm (in)	0.2 (0.008)					
THERMOSTATS								
Opening temperature		°C (°F)	48 - 52 (118 - 126)					
Full-open temperature		°C (°F)	60 (140)					
Valve open lower limit		mm (in)	3 (0.12)					
ENGINE SPEED								
Idling speed		r/min	700 ± 30					



LOWER UNIT

Item			Unit	Model	
	Worldwide			Z200NETO	LZ200NETO
	USA			Z200TR	LZ200TR
	Canada			Z200TR	—
GEAR BACKLASH					
Pinion - forward gear			mm (in)	0.25 - 0.46 (0.010 - 0.018)	0.21 - 0.43 (0.008 - 0.017)
Pinion - reverse gear			mm (in)	0.74 - 1.29 (0.029 - 0.051)	0.97 - 1.29 (0.038 - 0.051)
Pinion shims			mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50	
Forward gear shims			mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50	
Reverse gear shims			mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50	

ELECTRICAL

Item			Unit	Model	
	Worldwide			Z200NETO	LZ200NETO
	USA			Z200TR	LZ200TR
	Canada			Z200TR	—
IGNITION SYSTEM					
Ignition timing					
#1 cylinder					
@ idling speed (700 r/min)			Degree		BTDC 4
@ 5,500 r/min			Degree		BTDC 17
#2 cylinder					
@ idling speed (700 r/min)			Degree		BTDC 4
@ 5,500 r/min			Degree		BTDC 15
Fuse 1			V-A		12-80
Fuse 2			V-A		12-30
Fuse 3			V-A		12-20
Control unit (B/O, B/Y, B/L, B/Br, B/G, B/W - R/Y)					
Output peak voltage lower limit					
@ cranking 1*			V		—
@ cranking 2*			V		140
@ 1,500 r/min			V		205
@ 3,500 r/min			V		220

* Cranking 1: unloaded
Cranking 2: loaded



Item	Model			
	Worldwide			
	USA	Z200NETO		
	Canada	LZ200NETO		
		Unit	Z200TR	LZ200TR
Pulser coil (W/R, W/Y, W/G, W/B, W/L, W/Br - B)				
Output peak voltage lower limit				
@ cranking 1*	V		5.0	
@ cranking 2*	V		5.0	
@ 1,500 r/min	V		20	
@ 3,500 r/min	V		35	
IGNITION CONTROL SYSTEM				
Crank position sensor (G/L)				
Crank-position-sensor-to-flywheel gap	mm (in)		1.0 ± 0.5 (0.04 ± 0.02)	
Output peak voltage lower limit				
@ cranking 1*	V		4.5	
@ cranking 2*	V		4.0	
@ 1,500 r/min	V		13	
@ 3,500 r/min	V		20	
Engine cooling water temperature sensor				
Resistance (B/Y - B/Y)				
@ 5°C (41°F)	kΩ		128	
@ 20°C (68°F)	kΩ		54 - 69	
@ 100°C (212°F)	kΩ		3.02 - 3.48	
Throttle position sensor				
Input voltage (O - R)	V		4.75 - 5.25	
Output voltage (P - O)	V		0.48 - 5.25	
Thermo switch (P - B)				
OFF → ON	°C (°F)		84 - 90 (183 - 194)	
ON → OFF	°C (°F)		60 - 74 (140 - 165)	
FUEL CONTROL SYSTEM				
Oxygen density sensor				
* Heater resistance (R/W - B)	Ω		2 - 100	
Output voltage (Gy - B/W)	V		0.0 - 1.0	
Atmospheric pressure sensor				
Output voltage (at 101.32 kPa) (P - B)	V		3.2 - 4.6	
Intake air temperature sensor				
Resistance (B/Y - B/Y)	kΩ		1.5 - 4.0	

* Cranking 1: unloaded
 Cranking 2: loaded



Item			Unit	Model	
				Z200NETO	LZ200NETO
				Z200TR	LZ200TR
				Z200TR	—
Injector driver (O/R – Pu/R, O/B – Pu/B, O/Y – Pu/Y, O/G – Pu/G, O/L – Pu/L, O/W – Pu/W)					
Output peak voltage lower limit					
@ cranking 1*		V			65
@ cranking 2*		V			60
@ 1,500 r/min		V			65
@ 3,500 r/min		V			65
Fuel pressure sensor					
Output voltage (P – B)		V			2.8 - 3.2
STARTER MOTOR					
Type					Sliding gear
Output		kW			1.4
Cranking time limit		Second			30
Brushes					
Standard length		mm (in)			15.5 (0.61)
Wear limit		mm (in)			9.5 (0.37)
Commutator					
Standard diameter		mm (in)			29.0 (1.14)
Wear limit		mm (in)			28.0 (1.10)
Mica					
Standard undercut		mm (in)			0.5 - 0.8 (0.02 - 0.03)
Wear limit		mm (in)			0.2 (0.01)


* Cranking 1: unloaded
Cranking 2: loaded



Item	Worldwide		Unit	Model	
	USA			Z200NETO	LZ200NETO
	Canada			Z200TR	LZ200TR
				Z200TR	—
CHARGING SYSTEM					
Rectifier/regulator (R - B)					
Output peak voltage lower limit					
@ cranking 1*		V		—	
@ cranking 2*		V		7.5	
@ 1,500 r/min		V		12.7	
@ 3,500 r/min		V		12.7	
Lighting coil (G - G)					
Output peak voltage lower limit					
@ cranking (unloaded)		V		5.5	
@ 1,500 r/min (unloaded)		V		37	
@ 3,500 r/min (unloaded)		V		86	
OIL FEED PUMP CONTROL SYSTEM					
Oil level sensor (engine oil tank)					
Float position ① "OFF"		mm (in)		3 - 6 (0.12 - 0.24)	
Float position ② "ON"		mm (in)		33 - 36 (1.30 - 1.42)	
Float position ③ "ON"		mm (in)		53 - 56 (2.09 - 2.20)	
Oil level switch (sub-oil tank)					
Float position ④ "ON"		mm (in)		150 - 153 (5.91 - 6.02)	
POWER TRIM AND TILT SYSTEM					
Trim sensor					
Setting resistance		Ω		11 ± 7	
Resistance (P - B)		Ω		10 - 309	
POWER TRIM AND TILT MOTOR					
Fluid type				ATF Dexron II	
Brushes					
* Standard length		mm (in)		9.8 (0.39)	
Wear limit		mm (in)		4.8 (0.19)	
Commutator					
Standard diameter		mm (in)		22.0 (0.87)	
Wear limit		mm (in)		21.0 (0.83)	
Mica					
Standard undercut		mm (in)		1.35 (0.05)	
Wear limit		mm (in)		0.85 (0.03)	


* Cranking 1: unloaded
Cranking 2: loaded

DIMENSIONS






	Symbol		Unit	Model				
	Worldwide			Z150PETO	LZ150PETO	Z175GETO	Z200NETO	LZ200NETO
	USA			Z150TR	LZ150TR	Z175TR	Z200TR	LZ200TR
	Canada		Z150TR	—	—	Z200TR	—	
L1			mm (in)	613 (24.1)				
L2			mm (in)	180 (7.1)				
L3			mm (in)	—				
L4			mm (in)	646 (25.4)				
L5	(L)		mm (in)	53 (2.1)	—		53 (2.1)	—
	(X)		mm (in)	69 (2.7)				
L6	(L)		mm (in)	1,034 (40.7)	—		1,034 (40.7)	—
	(X)		mm (in)	1,150 (45.3)				
L7			mm (in)	574 (22.6)				
L8			mm (in)	168 (6.6)				
L9	(L)		mm (in)	42 (1.7)	—		42 (1.7)	—
	(X)		mm (in)	50 (2.0)				
L10			mm (in)	74 (2.9)				
H1	(L)		mm (in)	947 (37.3)	—		947 (37.3)	—
	(X)		mm (in)	1,074 (42.3)				
H2			mm (in)	708 (27.9)				
H3			mm (in)	211 (8.3)				
H4	(L)		mm (in)	516 (20.3)	—		516 (20.3)	—
	(X)		mm (in)	643 (25.3)				
H5			mm (in)	—				
H6	(L)		mm (in)	774 (30.5)	—		774 (30.5)	—
	(X)		mm (in)	850 (33.4)				
H7			mm (in)	308 (12.1)				
H8			mm (in)	14 (0.6)				
H9			mm (in)	835 (32.9)				
H10			mm (in)	44 (1.7)				
H11	(L)		mm (in)	32.2 (1.27)	—		32.2 (1.27)	—
	(X)		mm (in)	31.9 (1.26)				
W1			mm (in)	277 (10.9)				
W2			mm (in)	—				
W3			mm (in)	—				
W4			mm (in)	—				
W5			mm (in)	396 (15.6)				
W6			mm (in)	—				
A1			Degree	32				
A2			Degree	70				
A3			Degree	4				
T1			mm (in)	660 (26.0)				





	Symbol		Unit	Model	
	Worldwide			Z150QETO	Z175HETO
	USA			VZ150TR	VZ175TR
	Canada			VZ150TR	VZ175TR
L1		mm (in)	613 (24.1)		
L2		mm (in)	180 (7.1)		
L3		mm (in)	—		
L4		mm (in)	646 (25.4)		
L5	(L)	mm (in)	53 (2.1)		
	(X)	mm (in)	—		
L6	(L)	mm (in)	1,034 (40.7)		
	(X)	mm (in)	—		
L7		mm (in)	574 (22.6)		
L8		mm (in)	168 (6.6)		
L9	(L)	mm (in)	42 (1.7)		
	(X)	mm (in)	—		
L10		mm (in)	74 (2.9)		
H1	(L)	mm (in)	947 (37.3)		
	(X)	mm (in)	—		
H2		mm (in)	945 (37.2)		
H3		mm (in)	211 (8.3)		
H4	(L)	mm (in)	516 (20.3)		
	(X)	mm (in)	—		
H5		mm (in)	—		
H6	(L)	mm (in)	774 (30.5)		
	(X)	mm (in)	—		
H7		mm (in)	308 (12.1)		
H8		mm (in)	14 (0.6)		
H9		mm (in)	746 (29.4)		
H10		mm (in)	44 (1.7)		
H11	(L)	mm (in)	32.2 (1.27)		
	(X)	mm (in)	—		
W1		mm (in)	277 (10.9)		
W2		mm (in)	—		
W3		mm (in)	—		
W4		mm (in)	—		
W5		mm (in)	396 (15.6)		
W6		mm (in)	—		
A1		Degree	32		
A2		Degree	70		
A3		Degree	4		
T1		mm (in)	660 (26.0)		



Symbol	Unit	Model							
		Z150PETO	LZ150PETO	Z150QETO	Z175GETO	Z175HETO	Z200NETO	LZ200NETO	
		Z150TR	LZ150TR	VZ150TR	Z175TR	VZ175TR	Z200TR	LZ200TR	
Worldwide									
USA									
Canada									
B1	mm (in)				125.4 (4.9)				
B2	mm (in)				254 (10.0)				
B3	mm (in)				163.5 (6.4)				
B4	mm (in)				50.8 (2.0)				
B5	mm (in)				180 (7.1)				
B6	mm (in)				367 (14.4)				
B7	mm (in)				—				
B8	mm (in)				—				
B9	mm (in)				18.5 (0.7)				
C1	mm (in)				82 (3.2)				
C2	mm (in)				—				
D1	mm (in)				13 (0.5)				
D2	mm (in)				55.5 (2.2)				



TIGHTENING TORQUES

E

TIGHTENING TORQUES SPECIFIED TORQUES

Part to be tightened	Thread size	Tightening torques			
		N•m	kgf•m	ft•lb	
POWER UNIT					
Intake silencer	M6	3	0.3	2.2	
Electric oil pump	M6	8	0.8	5.8	
Fuel injection unit	M6	10	1.0	7.2	
Atmospheric pressure sensor	M6	4	0.4	2.9	
Electric oil pump bracket	M6	8	0.8	5.8	
Throttle position sensor	M5	4	0.4	2.9	
Intake air temperature sensor	M12	8	0.8	5.8	
Drive belt tensioner	M10	40	4.0	29	
Mechanical fuel pump	M8	23	2.3	17	
Fuel rail	M8	23	2.3	17	
Fuel injector cap	M8	26	2.6	19	
Fuel filter nut holder	M6	8	0.8	5.8	
Oil pump	M6	7	0.7	5.1	
Emergency switch	—	4	0.4	2.9	
Flywheel magnet assembly	M20	190	19	137	
Negative battery lead	M8	18	1.8	13	
Positive battery lead	M8	9	0.9	6.5	
Junction box cover	M5	2	0.2	1.4	
Power trim and tilt lead (blue, green)	M6	4	0.4	2.9	
Apron	M6	8	0.8	5.8	
Power unit mount	M8	21	2.1	15	
Power trim and tilt lead (red)	—	9	0.9	6.5	
Starter relay holder	M5	3	0.3	2.2	
Oxygen density sensor cover	M6	9	0.9	6.5	
Oxygen density sensor bracket	M6	14	1.4	10	
Oxygen density sensor	M18	49	4.9	35	
Reed valve assembly	M6	10	1.0	7.2	
Reed valve	M5	3	0.3	2.2	
Reed valve stopper	M3	1	0.1	0.7	
Shift position switch	M4	3	0.3	2.2	
Spark plug	M14	25	2.5	18	
Thermostat cover	1st	M6	5	0.5	3.6
	2nd		11	1.1	8.0
Cylinder head cover	1st	M6	5	0.5	3.6
	2nd		11	1.1	8.0
Engine cooling water temperature sensor	—	15	1.5	11	
Cylinder head	1st	M8	15	1.5	11
	2nd		30	3.0	22
Cooling water pressure control valve cover	1st	M6	4	0.4	2.9
	2nd		8	0.8	5.8



Part to be tightened		Thread size	Tightening torques		
			N•m	kgf•m	ft•lb
Exhaust port outer cover	1st	M6	4	0.4	2.9
	2nd		8	0.8	5.8
Crankcase	1st	M8	10	1.0	7.2
	2nd		18	1.8	13
	1st	M10	20	2.0	14
	2nd		40	4.0	29
Connecting rod	1st	M8	19	1.9	14
	2nd		37	3.7	27
	3rd		*		
	4th		19	1.9	14
	5th		37	3.7	27
LOWER UNIT					
Propeller		M18	55	5.5	40
Lower unit		M10	40	4.0	29
Ring nut		—	145	14.5	105
Pinion nut		M22	95	9.5	68
Gear oil drain screw		—	7	0.7	5.1
Gear oil level check screw		—	7	0.7	5.1
BRACKET UNIT					
Flushing hose		M5	5	0.5	3.6
Shift rod detent mechanism screw		—	24	2.4	17
Upper mount		M12	53	5.3	38
Lower mount		M14	73	7.3	53
Exhaust manifold assembly		M8	21	2.1	15
Muffler		M8	18	1.8	13
Exhaust manifold		M8	18	1.8	13
Lower exhaust manifold guide		M8	18	1.8	13
Clamp bracket		M22	15	1.5	11
Trim sensor stopper		M6	3	0.3	2.2
Trim stopper		—	37	3.7	27
POWER TRIM AND TILT UNIT					
Power trim and tilt reservoir cap		—	8	0.8	5.8
Power trim and tilt reservoir		1/4"	5	0.5	3.6
Power trim and tilt motor		1/4"	5	0.5	3.6
Manual valve		—	4	0.4	2.9
Tilt ram end screw		—	130	13	94
Tilt piston nut		—	100	10	72
Gear pump unit		5/16"	9	0.9	6.5
Gear pump		—	6	0.6	4.3
Trim ram end screw		—	80	8.0	52

*: Loosen




Nut (A)	Bolt (B)	General torque specifications		
		N•m	kgf•m	ft•lb
8 mm	M5	5	0.5	3.6
10 mm	M6	8	0.8	5.8
12 mm	M8	18	1.8	13
14 mm	M10	36	3.6	25
17 mm	M12	43	4.3	31

GENERAL TORQUES

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided in applicable sections of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads.

Components should be at room temperature.



MAINTENANCE INTERVAL CHART

Use the following chart as a guide to general maintenance intervals.

Dependant on operating conditions, adjust the maintenance intervals accordingly.

Item	Remarks	Initial		Every	
		10 hours (Break-in)	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)
TOP COWLING					
Top cowling fit	Check				○
FUEL SYSTEM					
Fuel line	Check	○	○	○	
Fuel filter	Clean/check	○	○	○	
Mechanical fuel pump oil ^(*1)	Check				○
Fuel tank	Clean				○
POWER UNIT					
Water leakage	Check	○	○	○	
Motor exterior	Check	○	○	○	
Exhaust leakage	Check	○	○	○	
Cooling water passage ^(*2)	Clean		○	○	
CONTROL SYSTEM					
Throttle valve synchronization	Check/adjust				○
Engine idling speed	Check/adjust	○		○	
Throttle position sensor	Check/adjust				○
Remote control shift cable	Check/adjust				○
Remote control throttle cable	Check/adjust				○
Drive belt ^(*3)	Check				○
OIL INJECTION SYSTEM					
Oil tank water drain	Clean	○	○	○	
Oil pump lever	Check/adjust	○			
POWER TRIM AND TILT UNIT					
Power trim and tilt fluid	Check	○	○	○	
LOWER UNIT					
Gear oil	Change	○		○	
Lower unit leakage	Check				○
Propeller and cotter pin	Check/replace	○	○	○	

(*1) Be sure to replace the mechanical fuel pump oil after every 1,000 hours (5 years) of operation.

(*2) When operating in salt water, turbid or muddy water, the engine should be flushed with clean water after each use.

(*3) Be sure to replace the drive belt after every 1,000 hours (5 years) of operation.



MAINTENANCE INTERVAL CHART

E

Item	Remarks	Initial		Every	
		10 hours (Break-in)	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)
GENERAL					
Anodes	Check/replace		○	○	
Battery	Check/charge	(every month)			
Spark plugs	Clean/adjust/ replace	○	○	○	
Wiring and connectors	Adjust/reconnect	○	○	○	
Bolts and nuts	Tighten	○	○	○	
Lubrication points	Grease			○	



FUEL SYSTEM
MEASURING THE FUEL PRESSURE
(MEDIUM-PRESSURE FUEL LINE)

Measure:

- Fuel pressure (medium-pressure fuel line)
- Out of specification → Check the medium-pressure fuel line.



Fuel pressure
(medium-pressure fuel line)
280 - 360 kPa
(2.8 - 3.6 kgf/cm², 39.8 - 51.2 psi)

Measuring steps

- (1) Install the fuel pressure gauge onto the pressure check valve.





Fuel pressure gauge ①
YB-06766 / 90890-06786


- A** For USA and Canada
- B** For worldwide

⚠ WARNING


When attaching the fuel pressure gauge, first cover the connection between the gauge and the vapor separator pressure check valve with a clean, dry rag to prevent fuel from leaking out. Gently screw in the gauge until it is firmly attached.



- (2) Start the engine, run it at idle speed for 1 minute, and then measure the fuel pressure.
- (3) Cover the connection with a rag, and then remove the fuel pressure gauge.

**⚠ WARNING**For worldwide **B**

- Before measuring the fuel pressure, make sure the breather nut **a** is tightened securely.
- Do not loosen the breather nut while measuring the fuel pressure. Loosening the breather nut will cause fuel to spray out creating a fire hazard.
- After measuring the fuel pressure, cover the end of the hose with a clean, dry rag, point the hose downward, and then loosen the breather nut to drain the remaining fuel from the hose and gauge.
- When storing the fuel pressure gauge, make sure the breather nut is tightened securely.

**CHECKING THE FUEL PRESSURE
(MECHANICAL FUEL PUMP)**

Measure:

- Fuel pressure sensor output voltage
Out of specification → Check the high-pressure fuel line.

**Fuel pressure sensor output
voltage****Pink (P) – Black (B)
2.8 - 3.2 V****Measuring steps**

- (1) Remove the flywheel magnet assembly cover.
- (2) Connect the test harness between the fuel pressure sensor and the wire harness as shown.

**Test harness (3-pin)****YB-06769 / 90890-06769**

- (3) Start the engine, run it at idle speed.
- (4) Measure the fuel pressure sensor output voltage.
- (5) Install the flywheel magnet assembly cover.





CHECKING THE MECHANICAL FUEL PUMP OIL LEVEL

Check:

- Mechanical fuel pump oil level
- Level is low → Add to the proper level.



Recommended gear oil
GEAR CASE LUBE (USA) or
Hypoid gear oil SAE 90
Total amount
47 - 53 cm³ (1.59 - 1.79 US oz,
1.66 - 1.87 Imp oz)



Checking steps

- (1) Remove the flywheel magnet assembly cover.
- (2) Remove the gear oil level check screw ① and check the oil level using a thin screwdriver.
- (3) If the gear oil is insufficient, add gear oil, and then install the gear oil level check screw.

NOTE:

The gear oil level should be about 13 mm (0.51 in) ② below the mating surface of the mechanical fuel pump body and its cover.

- (4) Install the flywheel magnet assembly cover.


CHANGING THE MECHANICAL FUEL PUMP OIL

1. Place:

- Container



NOTE:

Place a container under the gear oil drain screw.




2. Remove:

- Flywheel magnet assembly cover
 - Gear oil drain screw ①
 - Gear oil level check screw ②
- Drain the gear oil.



3. Fill:
- Gear oil



Recommended gear oil
GEAR CASE LUBE (USA) or
Hypoid gear oil SAE 90
Total amount
47 - 53 cm³ (1.59 - 1.79 US oz,
1.66 - 1.87 Imp oz)

Filling steps


- (1) Insert the gear oil tube into the drain hole and slowly fill the gear oil until oil flows out of the check hole.
- (2) Install the gear oil level check screw and then quickly install the gear oil drain screw.

NOTE: _____
 The gear oil level should be about 13 mm (0.51 in) @ below the mating surface of the mechanical fuel pump body and its cover.

4. Install:
- Flywheel magnet assembly cover

CONTROL SYSTEM
ADJUSTING THE THROTTLE
POSITION SENSOR


1. Measure:
- Throttle position sensor output voltage (with the throttle valves fully closed)
 Out of specification → Adjust.



Throttle position sensor output voltage (pink (P) – orange (O))
0.50 ± 0.02 V

NOTE: _____

- Be sure to adjust the throttle valve's opening before measuring the throttle position sensor output voltage.
- When measuring the throttle position sensor output voltage, set the digital tester to the manual range.




Measuring steps

- (1) Disconnect the throttle link rod ① at the #1 throttle valve.
- (2) Connect the test harness (3-pin) as shown.



**Test harness (3-pin)
YB-06757 / 90890-06757**

- (3) Connect the digital tester probes to the test harness (3-pin) as shown.
- (4) Turn the engine start switch on.
- (5) Measure the output voltage (with the throttle valves fully closed).




2. Adjust:

- Throttle position sensor


Adjustment steps

- (1) Turn the engine start switch on.
- (2) Loosen the screws ②.
- (3) Adjust the position of the throttle position sensor until the specified output voltage is obtained.



**Throttle position sensor output
voltage (pink (P) – orange (O))
 0.50 ± 0.02 V**


- (4) Tighten the screws.
- (5) Connect the throttle link rod.
- (6) Measure the output voltage again.






ADJUSTING THE REMOTE CONTROL SHIFT CABLE (EXCEPT FOR Z150Q, Z175H/VZ150, VZ175)

1. Check:
 - Shift operation
 - Incorrect → Adjust.
2. Adjust:
 - Remote control shift cable length

Adjustment steps



- (1) Loosen the locknut ①.
- (2) Remove the clip ②.
- (3) Disconnect the shift cable joint from the set pin ③.
- (4) Shift the remote control lever several times into the forward, neutral, and reverse positions, before setting it into the neutral position.
- (5) Push the shift cable joint ③ all the way in, and then mark its position ① on the inner cable as shown in the illustration.
- (6) Pull the shift cable joint all the way out, and then mark its position ② on the inner cable as shown in the illustration.
- (7) Make the free play mark ③ on the inner cable directly between marks ① and ②.
- (8) Push the shift cable joint to the free play mark ③ as shown in the illustration.
- (9) Adjust the shift rod lever bushing ④ so that it is at the center of the shift rod lever bracket ⑤.
- (10) Adjust the position of the shift cable joint until its hole aligns with the set pin ①.



The shift cable joint must be screwed in more than 5.0 mm (0.20 in).

- (11) Connect the shift cable joint ③ to the set pin.
- (12) Install the clip ② and tighten the locknut ①.
- (13) Shift the remote control lever into the forward, neutral, and reverse positions to make sure that the shift position switch is working properly. If the switch does not operate properly, repeat the steps above.





ADJUSTING THE REMOTE CONTROL SHIFT CABLE (FOR Z150Q, Z175H/ VZ150, VZ175)

1. Check:
 - Shift operation
Incorrect → Adjust.
2. Adjust:
 - Remote control shift cable length

Adjustment steps

- (1) Loosen the locknut ①.
- (2) Remove the clip ②.
- (3) Disconnect the shift cable joint from the set pin ③.
- (4) Set the remote control lever to the neutral position.
- (5) Align the center of the set pin ④ with the mark ⑤ on the bottom cowling.
- (6) Adjust the position of the shift cable joint until its hole aligns with the set pin ③.




The shift cable joint must be screwed in more than 8.0 mm (0.31 in).


- (7) Connect the shift cable joint ③ to the set pin.
- (8) Install the clip ② and tighten the locknut ①.

ADJUSTING THE CRANK POSITION SENSOR

1. Measure:
 - Crank position sensor-to-flywheel magnet assembly clearance ①
Out of specification → Adjust.
Use a thickness gauge.




Crank position sensor-to-flywheel magnet assembly clearance
1.0 ± 0.5 mm (0.04 ± 0.02 in)



2. Adjust:
- Crank position sensor

Adjustment steps

- (1) Loosen the screws ①.
- (2) Adjust the position of the crank position sensor until the specified clearance is obtained.
- (3) Tighten the screws.



OIL INJECTION SYSTEM
AIR BLEEDING THE OIL INJECTION SYSTEM


- **DO NOT USE GASOLINE MIXED WITH OIL (PREMIX).**
- **USE UNLEADED STRAIGHT GASOLINE ONLY.**


Bleed:

- Air bubbles
(from the oil injection system)


Bleeding steps

- (1) Place rags around the air bleed screw ① to catch any oil that might spill.
- (2) Fill the oil tank with the engine oil.



	<p>Recommended engine oil Engine oil type 2-stroke outboard engine oil</p>
---	---

- (3) Disconnect the oil pump link rod joint from the oil pump lever.
- (4) Start the engine, run it at idle speed.
- (5) Loosen the air bleed screw ① and make sure that both the oil and air bubbles flow out.
- (6) When there are no air bubbles left, tighten the air bleed screw.
- (7) Disconnect an oil pump feed hose ② from the oil pump.
- (8) Check the oil flows from the oil pump.
- (9) Connect the oil pump feed hose.
- (10) Connect the oil pump link rod joint to the oil pump lever.



CHECKING THE ELECTRIC OIL PUMP

- **DO NOT USE GASOLINE MIXED WITH OIL (PREMIX).**
- **USE UNLEADED STRAIGHT GASOLINE ONLY.**

Check:

- Electric oil pump operation
Incorrect → Replace.

Checking steps

- (1) Disconnect the electric oil pump hose ① from the vapor separator.
- (2) Place the end of the electric oil pump hose with a rag.
- (3) Start the engine, run it at idle speed.
- (4) Check the oil flows from the electric oil pump hose end.
- (5) Connect the electric oil pump hose.


**POWER TRIM AND TILT SYSTEM
CHECKING THE POWER TRIM AND
TILT FLUID LEVEL**

Check:

- Power trim and tilt fluid level
Level is low → Add power trim and tilt fluid to the proper level.




**Recommended power trim and
tilt fluid
ATF Dexron II**



⚠ WARNING

When removing the power trim and tilt reservoir cap, the power trim and tilt fluid may spurt out due to internal pressure. Highly pressurized fluid could spray out causing serious injury. Therefore, fully tilt up the outboard (the tilt ram assembly fully extended) and then slowly remove the power trim and tilt reservoir cap.




Checking steps

- (1) Tilt the outboard all the way up and lock it with the tilt stop levers ①.

⚠ WARNING

After tilting up the outboard, be sure to support it with the tilt stop levers. Otherwise, the outboard could suddenly lower if the power trim and tilt unit should lose fluid pressure.



- (2) Remove the reservoir cap ② and check the fluid level.


NOTE:

The fluid level should be directly below the check hole as shown.

- (3) If the power trim and tilt fluid is insufficient, add fluid, and then install the reservoir cap.



Reservoir cap
8 N · m (0.8 kgf · m, 5.8 ft · lb)



ADJUSTING THE TRIM SENSOR CAM

1. Measure:


- Trim sensor setting resistance
- Out of specification → Adjust.



Trim sensor setting resistance
Pink (P) – Black (B)
11 ± 7 Ω at 20 °C (68 °F)

Measuring steps

- (1) Fully tilt the outboard down.
- (2) Measure the trim sensor resistance.




2. Adjust:


Trim sensor cam position

Adjusting steps

- (1) Fully tilt the outboard down.
- (2) Loosen the screw ①.
- (3) Adjust the position of the trim sensor cam ② until the specified resistance is obtained.

	<p>Trim sensor resistance Pink (P) – Black (B) $11 \pm 7 \Omega$ at 20 °C (68 °F)</p>
---	--

- (4) Tighten the screw.


	<p>Trim sensor cam screw 3 N · m (0.3 kgf · m, 2.2 ft · lb)</p>
---	--

LOWER UNIT

CHECKING THE GEAR OIL LEVEL

Check:

- Gear oil level
 Level is low → Add gear oil to the proper level.



CHANGING AND CHECKING THE GEAR OIL

1. Check:

- Gear oil
 Milky oil → Check or replace the oil seal.
 Slag oil → Check the gears, bearings, and clutch dog.


Checking steps

- (1) Tilt up the outboard slightly.
- (2) Place a container under the gear oil drain screw ①.
- (3) Remove the gear oil drain screw and gear oil level check screw ②.



2. Fill:

- Gear oil
(with the specified amount of the recommended gear oil)



	<p>Recommended gear oil GEAR CASE LUBE (USA) or Hypoid gear oil, SAE 90</p> <p>Total amount Regular rotation models 980 cm³ (33.1 US oz, 34.5 Imp oz) Counter rotation models 870 cm³ (29.4 US oz, 30.6 Imp oz)</p>
--	---

Filling steps

- (1) Place the outboard in a vertical position.
- (2) Insert the gear oil tube into the drain hole and slowly fill the gear oil until oil flows out of the check hole and no air bubbles are visible.
- (3) Install the gear oil level check screw and then quickly install the gear oil drain screw.

	<p>Gear oil level check screw 7 N · m (0.7 kgf · m, 5.1 ft · lb)</p> <p>Gear oil drain screw 7 N · m (0.7 kgf · m, 5.1 ft · lb)</p>
--	---

**CHECKING THE LOWER UNIT
(FOR AIR LEAKS)**


Check:

- Lower unit holding pressure
Pressure drops → Check the seals and components.

	<p>Lower unit holding pressure 100 kPa (1.0 kg/cm², 14.2 psi)</p>
--	---

Checking steps

Do not overpressurize the lower unit. Excessive pressure may damage the oil seals.




- (1) Remove the gear oil level check screw.
- (2) Install the leakage tester into the check hole.



Leakage tester
90890-06762

- (3) Apply the specified pressure.

NOTE: _____
The lower unit should hold the specified pressure for 10 seconds.



GENERAL
CHECKING THE SPARK PLUGS

Spark plug type
150 models: BKR6ES-11
175, 200 models: BKR7ES-11

1. Check:
 - Electrodes ①
Cracks/excessive wear → Replace.
 - Insulator color ②
Distinctly different color → Check the engine condition.





Color guide
Medium to light tan color
Normal
Whitish color

- Lean fuel mixture
- Plugged jet(-s)
- Air leak
- Wrong setting

Blackish color

- Rich mixture
- Excessive oil usage
- Defective ignition system
- Defective spark plug

2. Clean:
 - Spark plugs
(with a spark plug cleaner or wire brush.)



3. Measure:

- Spark plug gap ①
- Out of specification → Regap.



Spark plug gap
1.0 - 1.1 mm (0.039 - 0.043 in)

4. Tighten:

- Spark plugs



Spark plug
25 N • m (2.5 kgf • m, 18 ft • lb)

NOTE:

- Before installing the spark plug, clean the gasket surface and spark plug surface. Also, it is suggested to apply a thin film of anti-seize compound to the spark plug threads to prevent thread seizure.
- If a torque wrench is not available, a good estimate of the correct tightening torque is to finger tighten ① the spark plug and then tighten it another 1/4 to 1/2 of a turn ②.

CHECKING THE IGNITION TIMING

NOTE:

- Ignition timing is automatically controlled by the control unit. Therefore, only checking the procedure is shown in this section.
- Before checking the ignition timing, warm-up the engine. Correct checking cannot be obtained when the engine is cold.



Check:

- Ignition timing
Incorrect firing range → Check the ignition system components.



Ignition timing (cylinder #1)

150 (L transom) models

At idling speed (700 r/min):

BTDC 3°

At 5,500 r/min: BTDC 17°

175 models

At idling speed (700 r/min):

BTDC 3°

At 5,500 r/min: BTDC 20°

150 (X transom), 200 models


At idling speed (700 r/min):

BTDC 4°

At 5,500 r/min: BTDC 17°

Checking steps

- (1) Start the engine and allow it to warm up for several minutes.
- (2) Attach the engine tachometer and the timing light ① to the spark plug lead ② of cylinder #1.




Tachometer

YU-08036-B / 90890-06760

Timing light

YM-33277-A / 90890-03141

- (3) Aim the timing light ① at the flywheel cover window ③ and make sure the stationary pointer ④ is within the firing range ⑤ when engine is running with specified speed.





MEASURING THE COMPRESSION PRESSURE

⚠ WARNING


Before removing a spark plug, use compressed air to blow away dirt accumulated in the spark plug well to prevent it from falling into the cylinder that is being tested.

Measure:

- Compression pressure
- Excessive low compression pressure
→ Check the power unit components.



**Compression pressure
(reference data)**
650 kPa (6.5 kgf/cm², 92 psi)








Measuring steps

- (1) Start the engine and allow it to warm up for several minutes.
- (2) Stop the engine and remove the lock plate from the engine stop lanyard switch on the remote control box.
- (3) Remove the all spark plugs (six spark plugs).
- (4) Install the compression gauge ① into the spark plug hole.



Compression gauge
90890-03160

- (5) With the throttle wide open, crank the engine setting the main switch in the START position until the reading on the compression gauge stabilizes.
- (6) Remove the compression gauge and reinstall the all spark plugs.



LUBRICATION POINTS

1. Apply:

- Yamaha marine grease (for USA and Canada)
- Yamaha grease A (for worldwide)

2. Apply:


- Yamaha grease D



MEDIUM-PRESSURE FUEL LINE REDUCING THE FUEL PRESSURE (MEDIUM-PRESSURE FUEL LINE)

⚠ WARNING

Always reduce the fuel pressure in the medium-pressure fuel line before servicing the line or the vapor separator. If the fuel pressure is not released, pressurized fuel may spray out.



1. Reduce:

- Fuel pressure (medium-pressure fuel line)

NOTE:

To reduce the fuel pressure, cover the pressure check valve (a) of the vapor separator with a rag, and then press in the valve using a thin screwdriver (1).

2. Drain:

- Fuel

⚠ WARNING

Reduce the fuel pressure before removing the vapor separator drain screw, or pressurized fuel will spray out and may result in serious injury.


NOTE:

To drain the fuel from the vapor separator, place a container under it, and then remove the drain screw (2).

CHECKING THE PRESSURE REGULATOR

Check:

- Fuel pressure displacement
Faulty → Replace the pressure regulator.



Checking steps

- (1) Install the fuel pressure gauge onto the pressure check valve and then install the pressure/vacuum tester onto the pressure regulator vacuum hose.

	Fuel pressure gauge ①
	YB-06766 / 90890-06786
	Pressure/vacuum tester ②
	YB-35956-A / 90890-06756

- A** For USA and Canada
- B** For worldwide

⚠ WARNING

When attaching the fuel pressure gauge, first cover the connection between the gauge and the vapor separator pressure check valve with a clean, dry rag to prevent fuel from leaking out. Gently screw in the gauge until it is firmly attached.

- (2) Start the engine run it at idle speed.
- (3) Apply vacuum pressure with the pressure/vacuum tester.


	Vacuum pressure
	Approx. 35 kPa (0.35 kg/cm², 4.98 psi)

- (4) Check the fuel pressure displacement.

NOTE:

Make sure the fuel pressure in the medium-pressure fuel line lowers conversely in relation to the amount of pressure that is applied to the pressure regulator.

- (5) Cover the connection with a rag, and then remove the fuel pressure gauge.


**⚠ WARNING**

For worldwide **B**

- Before measuring the fuel pressure, make sure the breather nut **a** is tightened securely.
- Do not loosen the breather nut while measuring the fuel pressure. Loosening the breather nut will cause fuel to spray out creating a fire hazard.
- After measuring the fuel pressure, cover the end of the hose with a clean, dry rag, point the hose downward, and then loosen the breather nut to drain the remaining fuel from the hose and gauge.
- When storing the fuel pressure gauge, make sure the breather nut is tightened securely.



**VAPOR SEPARATOR
REMOVING/INSTALLING THE VAPOR SEPARATOR**




Order	Job/Part	Q'ty	Remarks
1	Atmospheric pressure sensor coupler, electric oil pump coupler, fuel inlet hose, fuel return hoses, electric oil pump hose, electric oil pump assembly, fuel feed hose and electric fuel pump connector Hose	1	Before performing the following procedure, reduce the fuel pressure (medium-pressure fuel line). (vapor separator and pressure regulator-to-throttle body)
2	Bolt	3	
3	Large washer	6	
4	Small washer	3	
5	Vapor separator	1	

Continued on next page.




ELECTRIC FUEL PUMP

DISASSEMBLING/ASSEMBLING THE ELECTRIC FUEL PUMP




Order	Job/Part	Q'ty	Remarks
1	Positive electric fuel pump terminal cap	1	(red lead)
2	Negative electric fuel pump terminal cap	1	(blue lead)
3	Nut	1	(M4) Ⓐ = 7 mm
4	Spring washer	1	
5	Nut	1	(M5) Ⓑ = 8 mm
6	Spring washer	1	
7	Positive electric fuel pump terminal	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
8	Negative electric fuel pump terminal	1	
9	O-ring	1	
10	Collar	1	
11	O-ring	1	
12	Electric fuel pump guide plate	1	
13	Electric fuel pump	1	
14	Coupler holder	1	
15	Terminal assembly	1	


Continued on next page.



Order	Job/Part	Q'ty	Remarks
16	O-ring	2	
17	Insulator	2	
18	O-ring	2	
19	Screw	2	
20	Float pin	1	
21	Float	1	
22	Clip	1	
23	Needle valve	1	
			For assembly, reverse the disassembly procedure.




**DRIVE BELT
REMOVING/INSTALLING THE DRIVE BELT**



Order	Job/Part	Q'ty	Remarks
	Flywheel magnet assembly cover		
1	Bolt	1	
2	Spring	1	
3	Drive belt tensioner	1	
4	Bolt	1	
5	Spring holder	1	
6	Drive belt	1	
7	Bolt	2	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
8	Tensioner bracket	1	
9	Bolt	1	
10	Drive sprocket plate	1	
11	Drive sprocket	1	
12	Dowel pin	1	
13	Nut	1	
14	Driven sprocket	1	
15	Woodruff key	1	
			For installation, reverse the removal procedure.



HIGH-PRESSURE FUEL LINE ASSEMBLY


E

HIGH-PRESSURE FUEL LINE ASSEMBLY DISASSEMBLING/ASSEMBLING THE HIGH-PRESSURE FUEL LINE ASSEMBLY



Order	Job/Part	Q'ty	Remarks
1	Fuel injector holder	6	
2	Fuel injector	6	
3	Seal ring (thin)	6	Not reusable
4	O-ring	6	Not reusable
5	Seal ring (thick)	6	Not reusable
6	Bolt	8	
7	Washer	8	
8	Fuel pipe	2	
9	Fuel rail	2	
10	Seal ring (thin)	8	Not reusable


Continued on next page.



Order	Job/Part	Q'ty	Remarks
11	O-ring	8	Not reusable
12	Seal ring (thick)	8	Not reusable
13	Bolt	1	
14	Washer	2	
15	Collar	1	
16	Bolt	1	
17	Mechanical fuel pump assembly	1	
18	Fuel feed hose joint	1	
19	Center fuel rail	1	
20	Screw	1	


Continued on next page.

**MECHANICAL FUEL PUMP
DISASSEMBLING/ASSEMBLING THE MECHANICAL FUEL PUMP BODY**




Order	Job/Part	Q'ty	Remarks
	Gear oil		
1	Gear oil drain screw	1	
2	Gasket	2	
3	Gear oil level check screw	1	
4	Clip	1	
5	Fuel return hose	1	(mechanical fuel pump regulator-to-hose joint)
6	Bolt	4	
7	Washer	4	
8	Mechanical fuel pump assembly	1	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
9	Mechanical fuel pump body	1	
10	Joint plate	1	
11	O-ring	1	Not reusable
12	Bolt	3	
13	Mechanical fuel pump body cover	1	
14	Camshaft	1	
15	O-ring	1	Not reusable
16	Bolt	2	
17	Washer	2	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
18	Collar	2	
19	Mechanical fuel pump regulator	1	
20	Bolt	2	
21	Washer	2	
22	Fuel return hose joint	1	
23	O-ring	1	Not reusable
24	Bolt	1	
25	Joint plate	1	
			For assembly, reverse the disassembly procedure.

**POWER UNIT
REMOVING/INSTALLING THE EXHAUST EXPANSION CHAMBER**




Order	Job/Part	Q'ty	Remarks
1	Screw	1	
2	Bolt	2	
3	Bolt	2	
4	Apron	1	
5	Collar	4	
6	Hose joint	1	
7	Rubber seal	1	
8	Bolt	9	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
9	Exhaust expansion chamber	1	
10	Exhaust expansion chamber hose	1	
11	Rubber seal	4	
12	Rubber seal	1	
13	Clip	1	
14	Cooling water hose	1	(exhaust manifold-to-power unit) For installation, reverse the removal procedure.




INSTALLING THE APRON

1. Install:
- Hose joint

NOTE:

First insert the hose joint ① in the exhaust expansion chamber hose ②, and then insert the apron securely in the hose joint.




2. Install:
- Apron



Make sure not to get the flushing hose ① caught between the mating surfaces ② of the apron when installing it.


**REED VALVES
CHECKING THE REED VALVE
ASSEMBLY**

1. Check:
 - Reed valve
Cracks/damage → Replace.





2. Measure:
 - Warpage limit @
Out of specification → Replace.

	Warpage limit 0.2 mm (0.008 in)
---	---




3. Measure:
 - Reed valve stopper height @
Out of specification → Replace.


	Reed valve stopper height 150, 175 models 8.1 ± 0.30 mm (0.32 ± 0.01 in) 200 models 9.0 ± 0.35 mm (0.35 ± 0.01 in)
---	---




**CRANKCASE
ASSEMBLING THE OIL SEAL
HOUSING**

- Install:
- Oil seal


	Bearing/oil seal attachment ① YB-06348, YB-41446 / 90890-06635, 90890-06630
	Driver rod ② YB-06229, YB-06071 / 90890-06606







**CYLINDER BODY ASSEMBLY
DISASSEMBLING THE UPPER
BEARING HOUSING**

- Remove:
- Needle bearing

	Needle bearing attachment..... ①
	YB-06205-1 / 90890-06663
	Driver rod ②
	90890-06606




- A** For USA and Canada
- B** For worldwide




**ASSEMBLING THE UPPER BEARING
HOUSING**

1. Install:
- Needle bearing


	Needle bearing attachment
	N.A. / 90890-06660



2. Install:
- Oil seal


	Bearing/oil seal attachment ①
	YB-41446 / 90890-06654
	Driver rod ②
	YB-06071 / 90890-06652

**LOWER UNIT (REGULAR ROTATION MODELS)
REMOVING/INSTALLING THE LOWER UNIT**




Order	Job/Part	Q'ty	Remarks
1	Speedometer hose	1	
2	Cotter pin	1	
3	Propeller nut	1	
4	Washer	1	
5	Washer	1	
6	Propeller	1	
7	Spacer	1	
8	Cap	1	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
9	Bolt	1	
10	Trim tab	1	
11	Bolt	1	
12	Bolt	6	
13	Lower unit	1	
14	Dowel pin	2	
15	Exhaust seal	1	
			For installation, reverse the removal procedure.




**PROPELLER SHAFT HOUSING ASSEMBLY (REGULAR ROTATION MODELS)
DISASSEMBLING THE PROPELLER SHAFT HOUSING**

1. Remove:
- Reverse gear

	Slide hammer..... ① YB-06096
	Bearing separator ② 90890-06534
	Guide plate..... ③ 90890-06501
	Guide plate stand ④ 90890-06538
	Bearing puller..... ⑤ 90890-06535
	Small universal claws ⑥ 90890-06536




- A** For USA and Canada
B For worldwide




2. Remove:
- Ball bearing


	Slide hammer..... ① YB-06096
	Guide plate..... ② 90890-06501
	Guide plate stand ③ 90890-06538
	Bearing puller..... ④ 90890-06535
	Small universal claws ⑤ 90890-06536





- A** For USA and Canada
B For worldwide



3. Remove:
- Oil seals
 - Needle bearing





	Bearing/oil seal attachment ① YB-06196 / 90890-06653
	Driver rod ② YB-06071 / 90890-06652



**ASSEMBLING THE PROPELLER
SHAFT HOUSING**

1. Install:
• Needle bearing

	Needle bearing installation position (a) 24.75 - 25.25 mm (0.974 - 0.994 in)
---	---

	Bearing/oil seal attachment (1) YB-06196 / 90890-06610
	Driver rod (2) YB-06071 / 90890-06604
	Bearing/oil seal depth plate (3) 90890-06603

- A** For USA and Canada
B For worldwide


2. Install:
• Oil seals

	Oil seal installation position (a) 4.75 - 5.25 mm (0.187 - 0.207 in)
---	--

	Bearing/oil seal attachment YB-06195 / 90890-06640
---	--

- A** For USA and Canada
B For worldwide


**DRIVE SHAFT (REGULAR ROTATION MODELS)
REMOVING/INSTALLING THE DRIVE SHAFT**




Order	Job/Part	Q'ty	Remarks
	Propeller shaft housing assembly		
1	Pinion nut	1	
2	Pinion	1	
3	Bolt	4	
4	Drive shaft housing assembly	1	
5	Pinion shim	*	
6	Thrust bearing	1	
7	Drive shaft	1	

Continued on next page.

*: As required





Order	Job/Part	Q'ty	Remarks
8	Forward gear assembly	1	
9	O-ring	1	
10	Oil seal cover	1	
11	Oil seal	2	
12	Needle bearing	1	
13	Drive shaft housing	1	
14	Tapered roller bearing	1	Not reusable
15	Needle bearing	2	Not reusable
16	Forward gear	1	
			For installation, reverse the removal procedure.




ASSEMBLING THE FORWARD GEAR ASSEMBLY

1. Install:
 • Needle bearings

	Needle bearing installation position ① 21.0 - 21.4 mm (0.827 - 0.843 in)
	Needle bearing installation position ② 4.5 - 4.9 mm (0.177 - 0.193 in)


	Bearing/oil seal attachment ① YB-06261 / 90890-06612
	Driver rod ② YB-06071 / 90890-06604
	Bearing/oil seal depth plate ③ 90890-06603



2. Install:
 • Tapered roller bearing


	Bearing/oil seal attachment YB-06434 / 90890-06660
---	--


- A** For USA and Canada
B For worldwide




ASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY


1. Install:
 • Needle bearing

	Position ① 5.75 - 6.25 mm (0.226 - 0.246 in)
---	--

	Bearing/oil seal attachment ① YB-06196 / 90890-06610
	Driver rod ② YB-06071 / 90890-06604
	Bearing/oil seal depth plate ③ 90890-06603


- A** For USA and Canada
B For worldwide






2. Install:
• Oil seals


	Oil seal installation position ② 0.25 - 0.75 mm (0.010 - 0.030 in)
---	--


	Bearing/oil seal attachment ① YB-06195 / 90890-06633
	Driver rod ② YB-06071 / 90890-06606




INSTALLING THE PINION

Install:
• Pinion
• Pinion nut

	Drive shaft holder ① YB-06201 / 90890-06520
	Pinion nut holder ② 90890-06505
	Pinion nut holder attachment . ③ 90890-06507


	Pinion nut 95 N • m (9.5 kgf • m, 68 ft • lb)
---	---

**LOWER CASE ASSEMBLY (REGULAR ROTATION MODELS)
DISASSEMBLING/ASSEMBLING THE LOWER CASE ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
	Forward gear		
1	Drive shaft sleeve	1	
2	Needle bearing	18	
3	Needle bearing outer race	1	
4	Tapered roller bearing outer race	1	
5	Forward gear shim	*	
6	Water seal	1	
7	Water seal seat	1	
			For assembly, reverse the disassembly procedure.


*: As required



DISASSEMBLING THE LOWER CASE ASSEMBLY


1. Remove:
- Needle bearing outer race

	Bearing/oil seal attachment ①
	YB-06194 / 90890-06636
	Driver rod ②
	YB-06071 / 90890-06605




2. Remove:
- Tapered roller bearing outer race
 - Forward gear shim(s)

	Slide hammer..... ①
	YB-06096
	Bearing puller..... ②
	90890-06523
	Large universal claws..... ③
	90890-06532




- A** For USA and Canada
B For worldwide



ASSEMBLING THE LOWER CASE ASSEMBLY

1. Install:
- Forward gear shim(s)
 - Tapered roller bearing outer race


	Bearing/oil seal attachment ①
	YB-06258 / 90890-06619
	Driver rod ②
	YB-06071 / 90890-06605



2. Install:
- Needle bearing outer race


	Bearing/oil seal attachment ①
	YB-06246 / 90890-06655
	Bearing puller..... ②
	YB-06029 / 90890-06523
	Needle bearing installation plate..... ③
	YB-06430

**LOWER UNIT (COUNTER ROTATION MODELS)
REMOVING/INSTALLING THE LOWER UNIT**





Order	Job/Part	Q'ty	Remarks
1	Cotter pin	1	
2	Propeller nut	1	
3	Washer	1	
4	Washer	1	
5	Propeller	1	
6	Spacer	1	
7	Cap	1	

Continued on next page.





Order	Job/Part	Q'ty	Remarks
8	Bolt	1	
9	Trim tab	1	
10	Bolt	1	
11	Bolt	6	
12	Lower unit	1	
13	Dowel pin	2	
14	Exhaust seal	1	
			For installation, reverse the removal procedure.





**PROPELLER SHAFT HOUSING ASSEMBLY (COUNTER ROTATION MODELS)
ASSEMBLING THE PROPELLER SHAFT HOUSING**

1. Install:
• Needle bearing

	Needle bearing installation position (a) 24.75 - 25.25 mm (0.974 - 0.994 in)
---	---


	Bearing/oil seal attachment (1) YB-06196 / 90890-06610
	Driver rod (2) YB-06071 / 90890-06604
	Bearing/oil seal depth plate (3) 90890-06603

- A** For USA and Canada
B For worldwide




2. Install:
• Oil seals

	Oil seal installation position (a) 4.75 - 5.25 mm (0.187 - 0.207 in)
---	--

	Bearing/oil seal attachment YB-06195 / 90890-06640
---	--

- A** For USA and Canada
B For worldwide


**DRIVE SHAFT (COUNTER ROTATION MODELS)
REMOVING/INSTALLING THE DRIVE SHAFT**



Order	Job/Part	Q'ty	Remarks
	Propeller shaft housing assembly		
1	Pinion nut	1	
2	Pinion	1	
3	Bolt	4	
4	Drive shaft housing assembly	1	
5	Pinion shim	*	
6	Thrust bearing	1	
7	Drive shaft	1	
8	Reverse gear assembly	1	


Continued on next page.

*: As required




Order	Job/Part	Q'ty	Remarks
9	Thrust bearing	1	
10	O-ring	1	
11	Oil seal cover	1	
12	Oil seal	2	
13	Needle bearing	1	
14	Drive shaft housing	1	
15	Roller bearing inner race	1	
16	Needle bearing	2	Not reusable
17	Reverse gear	1	


For installation, reverse the removal procedure.



REMOVING THE PINION


- Remove:
- Pinion nut
 - Pinion


	Drive shaft holder ① YB-06201 / 90890-06520
	Pinion nut holder ② 90890-06505
	Pinion nut holder attachment . ③ 90890-06507




REMOVING THE REVERSE GEAR

- Remove:
- Reverse gear assembly
 - Thrust bearing

	Slide hammer ① YB-06096
	Bearing puller ② 90890-06535
	Small universal claws ③ 90890-06536





- A** For USA and Canada
B For worldwide



DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY


- Remove:
- Oil seals
 - Needle bearing


	Bearing/oil seal attachment ① YB-06196 / 90890-06610
	Driver rod ② YB-06071 / 90890-06652



DISASSEMBLING THE REVERSE GEAR ASSEMBLY


1. Remove:
- Roller bearing inner race

	Bearing separator YB-06219 / 90890-06534
---	---





2. Remove:
- Needle bearings



NOTE: _____
Do not reuse the bearing, always replace it with a new one.




ASSEMBLING THE REVERSE GEAR ASSEMBLY


1. Install:
- Needle bearings

	Needle bearing installation position ①
	21.0 - 21.4 mm (0.827 - 0.843 in)
	Needle bearing installation position ②
	4.5 - 4.9 mm (0.177 - 0.193 in)


	Bearing/oil seal attachment ①
	YB-06261 / 90890-06612
	Driver rod ②
	YB-06071 / 90890-06604
	Bearing/oil seal depth plate ③
	90890-06603







2. Install:
- Roller bearing inner race

	Bearing/oil seal attachment
	YB-06434 / 90890-06660


- A** For USA and Canada
B For worldwide






ASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY

1. Install:
- Needle bearing


 **Position (a)**
5.75 - 6.25 mm (0.226 - 0.246 in)

 **Bearing/oil seal attachment (1)**
YB-06196 / 90890-06610
Driver rod (2)
YB-06071 / 90890-06604
Bearing/oil seal depth plate (3)
90890-06603

- A** For USA and Canada
B For worldwide

2. Install:
- Oil seals


 **Oil seal installation position (a)**
0.25 - 0.75 mm (0.010 - 0.030 in)

 **Bearing/oil seal attachment ... (1)**
YB-06195 / 90890-06633
Driver rod (2)
YB-06071 / 90890-06606

INSTALLING THE REVERSE GEAR


- Install:
- Thrust bearing
 - Reverse gear assembly

NOTE: _____
Install the thrust bearing onto the reverse gear assembly and position the thrust bearing so its rounded side faces away from the reverse gear.




INSTALLING THE PINION

- Install:
- Pinion
 - Pinion nut


	Drive shaft holder ①
	YB-06201 / 90890-06520
	Pinion nut holder ②
	90890-06505
	Pinion nut holder attachment . ③
	90890-06507


	Pinion nut
	95 N • m (9.5 kgf • m, 68 ft • lb)



**LOWER CASE ASSEMBLY
(COUNTER ROTATION MODELS)
ASSEMBLING THE LOWER CASE
ASSEMBLY**

1. Install:
- Reverse gear shim(s)
 - Roller bearing

	Bearing/oil seal attachment ①
	YB-06336 / 90890-06629
	Driver rod ②
	YB-06071 / 90890-06605



2. Install:
- Needle bearing outer race

	Bearing/oil seal attachment ①
	YB-06246 / 90890-06655
	Bearing puller ②
	YB-06029 / 90890-06523
	Needle bearing installation plate ③
	YB-06430



SHIMMING (REGULAR ROTATION MODELS) (FOR USA AND CANADA)


E




SHIMMING (REGULAR ROTATION MODELS) (FOR USA AND CANADA)

NOTE: _____

- There is no need to select shims when reassembling with the original case and inner parts.
- Shim calculations are required when reassembling with the original inner parts and a new case (the difference between the original inner parts and the new case).
- Measurements and adjustments are required when replacing the inner part(s).

*: 17.2 (except for Z150Q/VZ150)
16.3 (for Z150Q/VZ150)





SELECTING THE REVERSE GEAR SHIMS

NOTE: Find the shim thickness (T2) by selecting shims until the specified value (M0) is obtained with the special tool.

1. Measure:
 - Specified measurement (M)
 - Out of specified value (M0) → Adjust.

Specified value (M0) =
Except for Z150Q/VZ150
 1.80 - R/100 mm
For Z150Q/VZ150
 0.90 - R/100 mm

Measuring steps

- (1) Calculate the specified value (M0).

NOTE: "R" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "R" mark is missing or unreadable, assume an "R" value of "0", and check the backlash when the unit is assembled.

Example (except for Z150Q/VZ150):


If "R" is "+5", then
 $M0 = 1.80 - (+5)/100 \text{ mm}$
 $= 1.80 - 0.05 \text{ mm}$
 $= 1.75 \text{ mm}$

If "R" is "-3", then
 $M0 = 1.80 - (-3)/100 \text{ mm}$
 $= 1.80 + 0.03 \text{ mm}$
 $= 1.83 \text{ mm}$


Example (for Z150Q/VZ150):

If "R" is "+5", then
 $M0 = 0.90 - (+5)/100 \text{ mm}$
 $= 0.90 - 0.05 \text{ mm}$
 $= 0.85 \text{ mm}$

If "R" is "-3", then
 $M0 = 0.90 - (-3)/100 \text{ mm}$
 $= 0.90 + 0.03 \text{ mm}$
 $= 0.93 \text{ mm}$



(2) Install the shimming gauge, bearing, thrust washer, reverse gear, and shim(s).

	Shimming gauge YB-34468-1A
---	---------------------------------------


NOTE: _____

- If the original shim(s) is unavailable, start with a 0.50-mm shim.
- Turn the reverse gear assembly a few times until the gear and bearing are horizontal.

(3) Measure the specified measurement (M).

2. Adjust:

- Shim thickness (T2)
Remove or add shim(s).

	Available shim thickness 0.10, 0.12, 0.15, 0.18, 0.30, 0.40 and 0.50 mm
--	--

NOTE: _____

(M0) – (M) should be as close to “0” as possible.



SHIMMING (REGULAR ROTATION MODELS) (FOR WORLDWIDE)


E




SHIMMING (REGULAR ROTATION MODELS) (FOR WORLDWIDE)

NOTE:

- There is no need to select shims when reassembling with the original case and inner parts.
- Shim calculations are required when reassembling with the original inner parts and a new case (the difference between the original inner parts and the new case).
- Measurements and adjustments are required when replacing the inner part(s).

*: 17.2 (except for Z150Q/VZ150)
16.3 (for Z150Q/VZ150)





SELECTING THE REVERSE GEAR SHIMS

NOTE: _____
Select the shim thickness (T2) by using the specified measurement(s) and the calculation formula.

- Select:
- Shim thickness (T2)


Selecting steps
(1) Measure (M2).

	Shimming plate ① 90890-06701
	Digital caliper ② 90890-06704

NOTE: _____

- Measure the height of the gear as shown.
- Perform the same measurement at three points on the gear.
- Find the average of the measurements (M2).

(2) Calculate the reverse gear shim thickness (T2).

	Reverse gear shim thickness Except for Z150Q/VZ150 (T2) = M2 - 29.0 - R/100 For Z150Q/VZ150 (T2) = M2 - 29.9 - R/100
---	---

NOTE: _____


“R” is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the “R” mark is missing or unreadable, assume a “R” value of “0”, and check the backlash when the unit is assembled.

Example (except for Z150Q/VZ150):
 If M2 is "30.50", R is "+2", then
 $T2 = 30.50 - 29.0 - (+2)/100 \text{ mm}$
 $= 30.50 - 29.0 - 0.02 \text{ mm}$
 $= 1.48 \text{ mm}$

Example (for Z150Q/VZ150):
 If M2 is "30.50", R is "+2", then
 $T2 = 30.50 - 29.9 - (+2)/100 \text{ mm}$
 $= 30.50 - 29.9 - 0.02 \text{ mm}$
 $= 0.58 \text{ mm}$

(3) Select the reverse gear shim(s) (T2).

Calculated numeral at 1/100th place		Rounded numeral
More than	or less	
0.00	0.02	0.02
0.02	0.05	0.05
0.05	0.08	0.08
0.08	0.10	0.10



Available shim thickness
 0.10, 0.12, 0.15, 0.18, 0.30, 0.40
 and 0.50 mm



BACKLASH (REGULAR ROTATION MODELS)


NOTE:

- Do not install the water pump components when measuring the backlash.
- Measure both the forward and reverse gear backlashes.
- If both the forward and reverse gear backlashes are larger than specification, the pinion may be too high.
- If both the forward and reverse gear backlashes are smaller than specification, the pinion may be too low.

MEASURING THE FORWARD GEAR BACKLASH

1. Measure:

- Forward gear backlash
Out of specification → Adjust.




Forward gear backlash
Except for Z150Q/VZ150
 0.25 - 0.46 mm
 (0.010 - 0.018 in)
For Z150Q/VZ150
 0.72 - 1.01 mm
 (0.028 - 0.040 in)

Measuring steps


- (1) Set the shift rod into the neutral position.





Shift rod wrench
 YB-06052 / 90890-06052




(2) Install the propeller shaft housing puller so it pushes against the propeller shaft.

	Propeller shaft housing puller ① YB-06207 / 90890-06502
	Universal puller ② YB-06117
	Guide plate ③ 90890-06501
	Center bolt ④ 90890-06504


	Center bolt 10 N · m (1.0 kgf · m, 7.2 ft · lb)
---	---



(3) Install the backlash indicator onto the drive shaft (on the 22.4 mm (0.88 in) diameter portion of the drive shaft).

	Backlash indicator ⑤ YB-06265 / 90890-06706
---	---


(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.


	Magnetic-base plate ⑥ YB-07003 / 90890-07003
	Dial gauge set ⑦ YU-03097 / 90890-01252
	Magnetic base ⑧ YU-34481 / 90890-06705

(5) Set the lower unit upside down.
 (6) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.

2. Adjust:

- Forward gear shim
Remove or add shim(s).

	Forward gear backlash (except for Z150Q/VZ150)	Shim thickness
	Less than 0.25 mm (0.010 in)	To be decreased by $(0.36 - M) \times 0.72$
	More than 0.46 mm (0.018 in)	To be increased by $(M - 0.36) \times 0.72$


	Forward gear backlash (for Z150Q/VZ150)	Shim thickness
	Less than 0.72 mm (0.028 in)	To be decreased by $(0.87 - M) \times 0.67$
	More than 1.01 mm (0.040 in)	To be increased by $(M - 0.87) \times 0.67$

M: Measurement

MEASURING THE REVERSE GEAR BACKLASH


1. Measure:


- Reverse gear backlash
Out of specification → Adjust.


	Reverse gear backlash Except for Z150Q/VZ150 0.74 - 1.29 mm (0.029 - 0.051 in) For Z150Q/VZ150 0.79 - 1.39 mm (0.031 - 0.055 in)
---	---

Measuring steps


- (1) Set the shift rod into the neutral position.




	Shift rod wrench YB-06052 / 90890-06052
---	--




- (2) Load the reverse gear by installing the propeller without the spacer ① and then tighten the propeller nut.


	<p>Propeller nut 10 N • m (1.0 kgf • m, 7.2 ft • lb)</p>
---	---



- (3) Install the backlash indicator onto the drive shaft (on the 22.4 mm (0.88 in) diameter portion of the drive shaft).

	<p>Backlash indicator ① YB-06265 / 90890-06706</p>
---	---


- (4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.


	<p>Magnetic-base plate..... ② YB-07003 / 90890-07003 Dial gauge set ③ YU-03097 / 90890-01252 Magnetic base..... ④ YU-34481 / 90890-06705</p>
--	---

- (5) Set the lower unit upside down.
 (6) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.

2. Adjust:

- Reverse gear shim
Remove or add shim(s).


 Reverse gear backlash (except for Z150Q/VZ150)	Shim thickness
Less than 0.74 mm (0.029 in)	To be increased by $(1.02 - M) \times 0.72$
More than 1.29 mm (0.051 in)	To be decreased by $(M - 1.02) \times 0.72$




 Reverse gear backlash (for Z150Q/VZ150)	Shim thickness
Less than 0.79 mm (0.031 in)	To be increased by $(1.09 - M) \times 0.67$
More than 1.39 mm (0.055 in)	To be decreased by $(M - 1.09) \times 0.67$

M: Measurement

SHIMMING (COUNTER ROTATION MODELS) (FOR USA AND CANADA)

- NOTE:**
- There is no need to select shims when reassembling with the original case and inner parts.
 - Shim calculations are required when reassembling with the original inner parts and a new case (the difference between the original inner parts and the new case).
 - Measurements and adjustments are required when replacing the inner part(s).






SELECTING THE FORWARD GEAR SHIMS

NOTE: _____
Find the shim thickness (T2) by selecting shims until the specified value (M0) is obtained with the special tool.

1. Measure:
- Specified measurement (M)
- Out of specified value (M0) → Adjust.




Specified value (M0) =
1.30 - R/100 mm

Measuring steps


- (1) Calculate the specified value (M0).

NOTE: _____
"R" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "R" mark is missing or unreadable, assume an "R" value of "0", and check the backlash when the unit is assembled.

Example:
If "R" is "+5", then
 $M0 = 1.30 - (+5)/100 \text{ mm}$
 $= 1.30 - 0.05 \text{ mm}$
 $= 1.25 \text{ mm}$
 If "R" is "-3", then
 $M0 = 1.30 - (-3)/100 \text{ mm}$
 $= 1.30 + 0.03 \text{ mm}$
 $= 1.33 \text{ mm}$



(2) Install the shimming gauge, bearing, thrust washer, forward gear, and shim(s).


	Shimming gauge YB-34468-1A
---	---------------------------------------

NOTE: _____

- If the original shim(s) is unavailable, start with a 0.50-mm shim.
- Turn the forward gear assembly a few times until the gear and bearing are horizontal.

(3) Measure the specified measurement (M).

2. Adjust:
- Shim thickness (T2)
Remove or add shim(s).

	Available shim thickness 0.10, 0.12, 0.15, 0.18, 0.30, 0.40 and 0.50 mm
--	--


NOTE: _____

(M0) – (M) should be as close to "0" as possible.

SHIMMING (COUNTER ROTATION MODELS) (FOR WORLDWIDE)

NOTE:

- There is no need to select shims when reassembling with the original case and inner parts.
- Shim calculations are required when reassembling with the original inner parts and a new case (the difference between the original inner parts and the new case).
- Measurements and adjustments are required when replacing the inner part(s).



**BACKLASH
(COUNTER ROTATION MODELS)**

- NOTE:**
- Do not install the water pump components when measuring the backlash.
 - Measure both the forward and reverse gear backlashes.
 - If both the forward and reverse gear backlashes are larger than specification, the pinion may be too high.
 - If both the forward and reverse gear backlashes are smaller than specification, the pinion may be too low.

MEASURING THE FORWARD GEAR BACKLASH

1. Measure:
- Forward gear backlash
- Out of specification → Adjust.


	Forward gear backlash 0.21 - 0.43 mm (0.008 - 0.017 in)
---	---

Measuring steps



- (1) Set the shift rod into the neutral position.


	Shift rod wrench YB-06052 / 90890-06052
---	---

- (2) Install the propeller shaft housing puller so it pushes against the propeller shaft.


	Propeller shaft housing puller . ① YB-06207 / 90890-06502
	Universal puller..... ② YB-06117
	Guide plate..... ③ 90890-06501
	Center bolt ④ 90890-06504

	Center bolt 10 N · m (1.0 kgf · m, 7.2 ft · lb)
---	---






(3) Install the backlash indicator onto the drive shaft (on the 22.4 mm (0.88 in) diameter portion of the drive shaft).


	Backlash indicator ⑤ YB-06265 / 90890-06706
---	--

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.

	Magnetic-base plate ⑥ YB-07003 / 90890-07003
	Dial gauge set ⑦ YU-03097 / 90890-01252
	Magnetic base ⑧ YU-34481 / 90890-06705

(5) Set the lower unit upside down.
 (6) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.


2. Adjust:
- Forward gear shim
Remove or add shim(s).


	Forward gear backlash	Shim thickness
	Less than 0.21 mm (0.008 in)	To be increased by $(0.32 - M) \times 0.72$
	More than 0.43 mm (0.017 in)	To be decreased by $(M - 0.32) \times 0.72$

M: Measurement

MEASURING THE REVERSE GEAR BACKLASH

1. Measure:
- Reverse gear backlash
Out of specification → Adjust.


	Reverse gear backlash 0.97 - 1.29 mm (0.038 - 0.051 in)
---	--




Measuring steps


(1) Set the shift rod into the neutral position.

	<p>Shift rod wrench YB-06052 / 90890-06052</p>
---	---




(2) Load the reverse gear by installing the propeller without the spacer ① and then tighten the propeller nut.




	<p>Propeller nut 5 N · m (0.5 kgf · m, 3.6 ft · lb)</p>
---	--




(3) Install the backlash indicator onto the drive shaft (on the 22.4 mm (0.88 in) diameter portion of the drive shaft).

	<p>Backlash indicator ① YB-06265 / 90890-06706</p>
---	---

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.



	<p>Magnetic-base plate ② YB-07003 / 90890-07003</p>
	<p>Dial gauge set ③ YU-03097 / 90890-01252</p>
	<p>Magnetic base ④ YU-34481 / 90890-06705</p>

(5) Set the lower unit upside down.



(6) Turn the shift rod into the reverse position with the shift rod wrench.

(7) Turn the drive shaft clockwise until the clutch dog is fully engaged.




- (8) Turn the shift rod into the neutral position with the shift rod wrench.
- (9) Turn the drive shaft counterclockwise approximately 30° more.

- (10) Turn the shift rod into the reverse position with the shift rod wrench.
- (11) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.


NOTE: _____
 When measuring the reverse gear backlash, turn the shift rod wrench slightly towards the reverse position.

- 2. Adjust:
 - Reverse gear shim
 Remove or add shim(s).


 Reverse gear backlash	Shim thickness
Less than 0.97 mm (0.038 in)	To be decreased by $(1.13 - M) \times 0.72$
More than 1.29 mm (0.051 in)	To be increased by $(M - 1.13) \times 0.72$

M: Measurement

**CLAMP BRACKETS
REMOVING/INSTALLING THE CLAMP BRACKETS**




Order	Job/Part	Q'ty	Remarks
	Upper case assembly		
1	Rubber cap	3	
2	Grease nipple	3	
3	Ground lead	1	
4	Bolt	4	
5	Ground lead	1	
6	Anode bracket	2	
7	Anode	1	
8	Trim sensor	1	Refer to "ADJUSTING THE TRIM SENSOR CAM" on page 45.
			Continued on next page.




Order	Job/Part	Q'ty	Remarks
9	Self-locking nut	1	
10	Bolt	2	
11	Clamp bracket bolt	1	
12	Starboard clamp bracket	1	
13	Port clamp bracket	1	
14	Bushing	2	
15	Swivel bracket assembly	1	
			For installation, reverse the removal procedure.

**TILT RAM ASSEMBLY AND GEAR PUMP UNIT
REMOVING/INSTALLING THE TILT RAM ASSEMBLY AND GEAR PUMP UNIT**




Order	Job/Part	Q'ty	Remarks
	Reservoir and power trim and tilt motor		
1	Manual valve	1	
2	Tilt ram end screw	1	
3	Tilt ram assembly	1	
4	O-ring	2	
5	Bolt	3	
6	Gear pump unit	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
7	Check valve assembly	1	
8	Bolt	2	
9	Gear pump	1	
10	Shuttle valve	2	
11	Check valve	2	
12	Up-relief valve assembly	1	
13	Down-relief valve assembly	1	
			For installation, reverse the removal procedure.



REMOVING THE TILT RAM END SCREW

- Loosen:
- Tilt ram end screw

	End screw wrench YX-06765 / 90890-06548
---	---

NOTE: _____


Hold the power trim and tilt unit in a vise using aluminum plates on both sides.


INSTALLING THE TILT RAM ASSEMBLY

⚠ WARNING _____

To prevent the hydraulic fluid from spurt-
ing out due to internal pressure, the tilt
ram should be kept at full length.

1. Fill:
- Tilt ram cylinder





	Recommended power trim and tilt fluid ATF Dexron II
---	---

NOTE: _____

Hold the power trim and tilt unit in a vise
using aluminum plates on both sides.


2. Fill:
- Gear pump housing



	Recommended power trim and tilt fluid ATF Dexron II
---	---

NOTE: _____


Add power trim and tilt fluid through the
hole ① until the fluid level is to the top of
the gear pump unit.



3. Install:
- Tilt ram assembly

NOTE:

Place the tilt ram end screw at the bottom of the tilt ram and install the tilt ram assembly into the tilt ram cylinder.




4. Tighten:
- Tilt ram end screw



End screw wrench
YX-06765 / 90890-06548



Tilt ram end screw
130 N · m (13 kgf · m, 94 ft · lb)


**TRIM RAM ASSEMBLIES AND
FREE PISTON
REMOVING THE TRIM RAM END
SCREWS**

- Loosen:
- Trim ram end screws




End screw wrench
YB-06175 / 90890-06548

NOTE:

Hold the power trim and tilt unit in a vise using aluminum plates on both sides.

INSTALLING THE TRIM RAMS
⚠ WARNING

Do not push the trim rams down while installing them into the trim ram cylinders. Otherwise, the hydraulic fluid may spurt out from the unit.




1. Fill:
- Trim ram cylinders



**Recommended power trim and tilt fluid
ATF Dexron II**

NOTE: _____
Hold the power trim and tilt unit in a vise using aluminum plates on both sides.




2. Fill:
- Fluid passages




**Recommended power trim and tilt fluid
ATF Dexron II**

NOTE: _____
Add power trim and tilt fluid through holes **a**, **b** and **c** until all of the passages are filled.



3. Install:
- Trim ram assemblies ①

NOTE: _____
Place each trim ram end screw at the bottom of each trim ram and install them into the trim ram cylinders.




4. Tighten:
- Trim ram end screws



**End screw wrench
YB-06175 / 90890-06548**



**Trim ram end screw
80 N • m (8.0 kgf • m, 58 ft • lb)**




**ELECTRICAL COMPONENTS ANALYSIS
DIGITAL CIRCUIT TESTER**

	<p>Digital tester YU-34899-A / 90890-06752</p>
---	---

NOTE: _____
 "○—○" indicates a continuity of electric-
 ity which means a closed circuit at the
 respective switch position.


MEASURING THE PEAK VOLTAGE



- NOTE:** _____
- When checking the condition of the ignition system it is useful to know the peak voltage.
 - Cranking speed is dependant on many factors (e.g., fouled or weak spark plugs, a weak battery). If one of these is defective, the peak voltage will be lower than specification.
 - If the peak voltage measurement is not within specification the engine will not operate properly.




PEAK VOLTAGE ADAPTOR

NOTE: _____
 The peak voltage adaptor should be used
 with the digital circuit tester.

	<p>Peak voltage adaptor YU-39991 / 90890-03172</p>
---	---

**NOTE:** _____

- When measuring the peak voltage, set the selector to the DC voltage mode.
- Make sure the peak voltage adaptor leads are properly installed in the digital tester.
- Make sure the positive pin (the “+” mark facing up as shown) on the peak voltage adaptor is installed into the positive terminal of the digital tester.
- The test harness is needed for the following tests.

**Measuring steps**

- (1) Disconnect the coupler connections.
- (2) Connect the test harness between the couplers.
- (3) Connect the peak voltage adaptor probes to the connectors which are being checked.
- (4) Start or crank the engine and observe the measurement.

MEASURING A LOW RESISTANCE

When measuring a resistance of $10\ \Omega$ or less with the digital tester, the correct measurement cannot be obtained because of the tester's internal resistance.

To obtain the correct value, subtract the internal resistance from the displayed measurement.



Correct value
Displayed measurement -
internal resistance

NOTE: _____


The internal resistance of the digital tester can be obtained by connecting both of its probes.



IGNITION CONTROL SYSTEM MEASURING THE THROTTLE POSITION SENSOR OUTPUT VOLTAGE

Measure:

- Throttle position sensor output voltage
- Out of specification → Check the control unit.



Throttle position sensor output voltage
Orange (O) – Pink (P)
0.48 - 5.25 V

Measuring steps


- (1) Connect the test harness (3-pin) as shown.



Test harness (3-pin)
YB-06757 / 90890-06757

- (2) Connect the battery leads to a 12-V battery.
- (3) Turn the engine switch to the on position.
- (4) Measure the throttle position sensor output voltage.

NOTE: _____
Make sure the throttle position sensor output voltage is within specification when the throttle is fully closed and fully opened.



FUEL CONTROL SYSTEM CHECKING THE FUEL PRESSURE SENSOR

Measure:

- Fuel pressure sensor output voltage
Out of specification → Replace.



**Fuel pressure sensor output
voltage**
Pink (P) – Black (B)
2.8 – 3.2 V



Measuring steps

- (1) Remove the flywheel magnet assembly cover.
- (2) Connect the test harness (3-pin) as shown.



Test harness (3-pin)
YB-06769 / 90890-06769

- (3) Start the engine, run it at idle speed.
- (4) Measure the fuel pressure sensor output voltage.
- (5) Install the flywheel magnet assembly cover.




**CHARGING SYSTEM
MEASURING THE LIGHTING COIL
OUTPUT PEAK VOLTAGE**

Measure:

- Lighting coil output peak voltage
Below specification → Replace the lighting coil.

	Lighting coil output peak voltage Green (G) – Green (G)		
r/min	Unloaded		
	Cranking	1,500	3,500
V	5.5	37	86

	Test harness (1-pin) YB-06788 / 90890-06788 Test harness (2-pin) YB-06787 / 90890-06787
--	--




**POWER TRIM AND TILT SYSTEM
MEASURING THE TRIM SENSOR
RESISTANCE**

Measure:

- Trim sensor resistance
Out of specification → Replace.


	Trim sensor resistance Pink (P) – Black (B) 10 - 309 Ω at 20 °C (68 °F)
--	--

NOTE: _____
Turn the lever ① and measure the resistance as it gradually changes.




**SELF-DIAGNOSIS
DIAGNOSIS CODE INDICATION**

1. Normal condition
(no defective part or irregular processing is found)
Single flash is given every 5 seconds.
Ⓐ : Light on, 0.3 second
Ⓑ : Light off, 5 seconds



2. Trouble code indication
Example: The illustration indicates code number 23.
Ⓐ : Light on, 0.3 second
Ⓑ : Light off, 0.3 second
Ⓒ : Light off, 1.7 seconds
Ⓓ : Light off, 5 seconds




**DIAGNOSIS THE ELECTRONIC
CONTROL SYSTEM**

1. Install:
 - Diagnostic indicator

	Diagnostic indicator YB-06444 / 90890-06765
--	---

NOTE: _____
When performing this diagnosis, all of the electrical wires must be properly connected.



2. Check:
 - Diagnosis code
Code 1 is indicated → Normal.
Code 13 - 28 indicated → Check the applicable parts.
Code 33 - 44 indicated → Microcomputer processing information.

Checking steps



- (1) Start the engine and let it idle.
- (2) Check the diagnostic indicator's flash pattern to determine if there are any malfunctions.

NOTE:

When more than one problem is detected, the diagnostic indicator's light flashes in the pattern of the lowest numbered problem. After that problem is corrected, the light flashes in the pattern of the next lowest numbered problem. This continues until all of the problems are detected and corrected.

Diagnosis code chart

Code	Symptoms
13	Incorrect pulser coil input signal
14	No crank position sensor input signal
15	Incorrect engine cooling water temperature sensor input signal
18	Incorrect throttle position sensor input signal
19	Low battery input voltage
22	Incorrect atmospheric pressure sensor input signal (out of normal operating range)
23	Incorrect intake air temperature sensor input signal
25	Incorrect fuel pressure sensor input signal
26	No injector operation signals
27	Water detection switch ON
28	Incorrect shift position switch input signal
33 ~ 44	Microcomputer processing information
33	Ignition timing is being slightly corrected (when starting a cold engine)
44	Engine stop switch control operating



YAMAHA DIAGNOSTIC SYSTEM CONNECTING THE COMPUTER TO THE OUTBOARD

Connect:

- Communication cable ①
- Adapter ②



Yamaha Diagnostic System
68F-85300-00

NOTE: _____

Refer to the Yamaha Diagnostic System Instruction Manual for details on installing the software onto an IBM-compatible lap-top computer ③.

Connecting steps

- (1) Quit any applications that are running, and then turn off the computer.
- (2) Connect the communication cable to the 3-pin communication coupler of the outboard, the adapter and the communication port of your computer.

NOTE: _____


Use either the COM1 or COM2 port, and if necessary, set the serial port as specified in the computer's manual. Set the serial port where the RS232C (Dsub-9 pin) cable is connected to COM1 or COM2.

- (3) Connect the remote control to the outboard.
- (4) Connect the 12 V battery to the outboard.

NOTE: _____

The following items should be checked before starting the Yamaha Diagnostic System.

- The battery is properly charged and its specified gravity is within specification.
- There are no incorrect wiring connections.
- Wiring connections are properly secured and are not rusty.
- There are enough fuel and oil in each tank.



YAMAHA DIAGNOSTIC SYSTEM FUNCTION

NOTE:


With the 150, 175 and 200 models, the following seven functions of the Yamaha Diagnostic System can be used.

- Diagnosis
- Diagnosis Record
- Engine Monitor
- Stationary Test
- Active Test
- Data Logger
- ECM No.

(1) Diagnosis

With the engine main switch ON, the diagnosis codes of malfunctions recorded in the outboard's ECM, the diagnosis codes' corresponding part name, the results of the diagnosis, and the condition of the part are listed.


Eight items can be displayed at one time. To check the other items, scroll the display.



Code	Symptoms
13	Incorrect pulser coil input signal
14	No crank position sensor input signal
15	Incorrect engine cooling water temperature sensor input signal
18	Incorrect throttle position sensor input signal
19	Low battery input voltage
22	Incorrect atmospheric pressure sensor input signal (out of normal operating range)
23	Incorrect intake air temperature sensor input signal
25	Incorrect fuel pressure sensor input signal
26	No injector operation signals
27	Water detection switch ON
28	Incorrect shift position switch input signal
44	Engine stop switch control operating

22	Atmospheric press sensor	Normal
1 Check wiring for proper connection or damage 2 Check sensor resistance 3 Check output peak voltage		
Print [F1]	Use UP and DN arrow keys to scroll Use LH and RH arrow keys to move	
Save [F2]	Press F1 to print, F2 to save.	

NOTE: _____
 For troubleshooting procedures for sensors that have detected a malfunction, move the cursor to the sensor number, and follow the instructions that are displayed.




(2) Diagnosis Record

The diagnosis codes of malfunctions that have been recorded in the outboard's ECM, the diagnostic codes' corresponding part name, and the time when the malfunctions occurred are listed.

A maximum of six items can be displayed at one time. The last item displayed is for the water detection switch only. The latest occurrence appears on top. In addition, diagnosis codes stored in the ECM can be deleted.

NOTE: _____

- The diagnosis codes that are displayed are the same as those in the "Diagnosis" menu.
- For troubleshooting procedures for sensors that have detected a malfunction, move the cursor to the sensor number, and follow the instructions that are displayed.



(3) Engine Monitor

Each sensor status and the ECM data are displayed while the engine is running.

Sensing items:

- Sensors (engine cooling water temperature sensor, throttle position sensor, atmospheric pressure sensor, intake air temperature sensor and fuel pressure sensor)
- Voltage system (battery voltage)
- Switches (water detection switch, shift position switch and engine stop lanyard switch)
- Operation signals (ignition, injectors, electric oil pump)

Engine parameter	Data display	Unit	Comments
Engine speed	##00	r/min	Range: 500 to 7,000, in steps of 500 ("0" is displayed when the engine is stopped.)
Fuel pressure (5.0 ± 0.8)	#0.0	MPa	Range: 0 to 6, in steps of 0.5
Fuel pressure (725 ± 116)	##0.00	psi	Displays the fuel pressure converted to psi
Atmospheric pressure	##0.0	HPa	Displays the atmospheric pressure (in HPa) calculated based on the atmospheric pressure sensor measurement
Atmospheric pressure	#0.0	inHg	Displays the atmospheric pressure converted to inHg
Ignition timing	BTDC### TDC ATDC###	deg	Displays the ignition timing of cylinder #1 ("- " is displayed when the engine is stopped.)
Battery voltage (12 - 16)	#0.00	V	Range: 0 to 16, in steps of 1 V
Oxygen sensor voltage (0 - 1.0)	###	V	Range: 0 to 1.5, in steps of 0.1
TPS voltage (0.5 - 4.5)	###	V	Range: 0 to 5, in steps of 0.5
Throttle valve opening (0 - 105)	##0.0	deg	Displays the throttle valve opening angle calculated based on the throttle position sensor voltage
Fuel injection duration	##0.00	ms	Displays the fuel injection period for cylinder #1 ("0" is displayed when the engine is stopped.)
Water temperature (below 90)	##0.0	°C	Range: -20 to 100, in steps of 10
Water temperature (below 194)	##0.0	°F	Displays the water temperature converted to °F
Intake temperature (below 70)	##0.0	°C	Range: -20 to 100, in steps of 1
Intake temperature (below 158)	##0.0	°F	Displays the intake temperature converted to °F
Starter switch	ON/OFF		ON: Turned on/OFF: Turned off
Engine stop lanyard switch	ON/OFF		ON: Pushed/OFF: Free
Over-rev control release lead	ON/OFF		ON: Disconnected/OFF: Connected
Main switch	ON/OFF		ON: Turned on/OFF: Turned off
Shift position switch	ON/OFF		ON: In neutral/OFF: In gear
Water detection switch	ON/OFF		ON: Water in fuel filter/OFF: Normal
Oil level switch (remote tank)	ON/OFF		ON: Float on top/OFF: Float on bottom
Oil level switch 1 (engine tank)	ON/OFF		Top float ON: Float on top OFF: Float on bottom
Oil level switch 2 (engine tank)	ON/OFF		Middle float ON: Float on top OFF: Float on bottom

Engine parameter	Data display	Unit	Comments
Oil level switch 3 (engine tank)	ON/OFF		Bottom float ON: Float on top OFF: Float on bottom
Water temp switch (over heat)	ON/OFF		ON: High water temperature OFF: Medium-to-low water temperature
Dual engine system switch	ON/OFF		ON: Turned on/OFF: Turned off
Firing of cylinder #1	Yes/No		Yes: Ignition signal sent from ECM No: No ignition signal sent
Firing of cylinder #2	Yes/No		Yes: Ignition signal sent from ECM No: No ignition signal sent
Firing of cylinder #3	Yes/No		Yes: Ignition signal sent from ECM No: No ignition signal sent
Firing of cylinder #4	Yes/No		Yes: Ignition signal sent from ECM No: No ignition signal sent
Firing of cylinder #5	Yes/No		Yes: Ignition signal sent from ECM No: No ignition signal sent
Firing of cylinder #6	Yes/No		Yes: Ignition signal sent from ECM No: No ignition signal sent
Electric oil pump	Low/High		Low: Low oil injection High: High oil injection

(4) Stationary Test

With the engine off, four operation tests are performed.

- Ignition coil



Spark gap tester
YM-34487 / 90890-06754

A voltage is applied to the ignition coil of the selected cylinder, a spark is created in the spark gap tester, and then the ignition system is checked. Five sparks are created within five seconds.

- **Fuel injector**

A voltage is applied to the injector of the selected cylinder, the injector is activated, and then the fuel system is checked. The fuel is injected 20 items within two seconds.

- **Electric fuel pump**

A voltage is applied to the electric fuel pump, the electric fuel pump is operated for ten seconds.

- **Electric oil pump**

The electrical oil pump is operated by a signal sent from the ECM for six seconds. Enables to check if oil has been spurted out from the electrical oil pump

(5) **Active Test**

The ignition and fuel are cut for each cylinder, one at a time, and the engine speed is checked for changes to determine whether or not the cylinder is malfunctioning. (If there is no change in the engine speed, the cylinder is faulty.)

The ignition signal and the fuel injection are paused for five seconds.

(6) **Data Logger**


Two out of six items (engine speed, fuel pressure, battery voltage, oxygen density sensor, throttle position, and water temperature), are selected and 13 minutes of their recorded data are displayed on a graph. The operating time as compared to the engine speed and the total operating time are also displayed.

(7) **ECM No.**

The ECM part number is read from the outboard engine's ECM and is displayed.

WIRING DIAGRAM

Z150PETO, LZ150PETO, Z150QETO, Z175HETO, Z200NETO, LZ200NETO/
 Z150TR, LZ150TR, Z175TR, Z200TR, LZ200TR






COLOR CODE

● B : Black	● I/Y : Blue/yellow	○ Y : Yellow
● Br : Brown	● O/B : Orange/black	● B/B : Black/brown
● G : Green	● O/G : Orange/green	● B/G : Black/green
● Gy : Gray	● O/L : Orange/blue	● B/L : Black/blue
● I : Blue	● O/R : Orange/red	● B/O : Black/orange
● Lg : Light green	● O/W : Orange/white	● B/R : Black/red
● O : Orange	● O/Y : Orange/yellow	● B/W : Black/white
● P : Pink	● Pu/B : Purple/black	● B/Y : Black/yellow
● R : Red	● Pu/G : Purple/green	● G/R : Green/red
● Sb : Sky blue	● Pu/L : Purple/blue	● I/G : Blue/green
○ W : White	● Pu/R : Purple/red	● L/R : Blue/red
		● L/W : Blue/white

● Pu/W : Purple/white	● W/B : White/black	● W/Br : White/brown
● Pu/Y : Purple/yellow	● W/G : White/green	● W/L : White/blue
● R/L : Red/blue	● W/R : White/red	● W/Y : White/yellow
● R/W : Red/white	● Y/R : Yellow/red	

● Y : Yellow	● Pu/W : Purple/white
● B/B : Black/brown	● Pu/Y : Purple/yellow
● B/G : Black/green	● R/L : Red/blue
● B/L : Black/blue	● R/W : Red/white
● B/O : Black/orange	● R/Y : Red/yellow
● B/R : Black/red	● W/B : White/black
● B/W : Black/white	● W/Br : White/brown
● B/Y : Black/yellow	● W/G : White/green
● G/R : Green/red	● W/L : White/blue
● I/G : Blue/green	● W/R : White/red
● L/R : Blue/red	● W/Y : White/yellow
● L/W : Blue/white	● Y/R : Yellow/red

● Pu/W : Purple/white	● W/B : White/black	● W/Br : White/brown
● Pu/Y : Purple/yellow	● W/G : White/green	● W/L : White/blue
● R/L : Red/blue	● W/R : White/red	● W/Y : White/yellow
● R/W : Red/white	● Y/R : Yellow/red	



COLOR CODE

● B : Black	● L/Y : Blue/yellow
● Br : Brown	● O/B : Orange/black
● G : Green	● O/G : Orange/green
● Gy : Gray	● O/L : Orange/blue
● L : Blue	● O/R : Orange/red
● Lg : Light green	● O/W : Orange/white
● O : Orange	● O/Y : Orange/yellow
● P : Pink	● Pu/B : Purple/black
● R : Red	● Pu/G : Purple/green
● Sb : Sky blue	● Pu/L : Purple/blue
● W : White	● Pu/R : Purple/red
● Y : Yellow	● Pu/W : Purple/white
● B/Br : Black/brown	● Pu/Y : Purple/yellow
● B/G : Black/green	● R/l : Red/blue
● R/l : Black/blue	● R/W : Red/white
● B/O : Black/orange	● R/Y : Red/yellow
● B/R : Black/red	● W/B : White/black
● B/W : Black/white	● W/Br : White/brown
● B/Y : Black/yellow	● W/G : White/green
● G/R : Green/red	● W/l : White/blue
● L/G : Blue/green	● W/R : White/red
● l/R : Blue/red	● W/Y : White/yellow
● L/W : Blue/white	● Y/R : Yellow/red

⑧ Injector driver

1 : G	14 : Pu/G
2 : W/Br	15 : Pu/Y
3 : W/L	16 : Pu/B
4 : R/Y	17 : Pu/R
5 : B	18 : —
6 : Pu/W	19 : W/B
7 : O/W	20 : W/R
8 : Pu/L	21 : R/Y
9 : O/L	22 : B
10 : W/G	23 : O/G
11 : W/Y	24 : O/Y
12 : R/Y	25 : O/B
13 : B	26 : O/R

⑪ Control unit

1 : W/Br	19 : B	37 : Br	55 : B/Y	73 : W/G
2 : W/L	20 : B	38 : Y	56 : B/Y	74 : W/Y
3 : W/G	21 : L/Y	39 : W	57 : —	75 : W/B
4 : W/Y	22 : L/R	40 : Gy	58 : B/Y	76 : W/R
5 : W/B	23 : L	41 : B	59 : B/Y	77 : B
6 : W/R	24 : L/W	42 : B	60 : O	78 : Gy
7 : G	25 : B	43 : R	61 : P	79 : Gy
8 : B/Br	26 : B	44 : R	62 : B	80 : R/Y
9 : B/L	27 : L/W	45 : —	63 : O	81 : B
10 : B/G	28 : L/G	46 : —	64 : P	82 : W/B
11 : B/Y	29 : L/R	47 : L/Y	65 : B	83 : —
12 : B/W	30 : L/R	48 : B	66 : O	84 : —
13 : B/O	31 : B/R	49 : L	67 : P	85 : —
14 : B	32 : Y/R	50 : W/R	68 : B	86 : —
15 : L	33 : G/R	51 : —	69 : B/W	
16 : L	34 : G	52 : —	70 : Gy	
17 : —	35 : P	53 : G	71 : W/Br	
18 : —	36 : P	54 : G	72 : W/L	

⑫ Fuse holder

1 : R	11 : R/Y	21 : R/W
2 : B	12 : R/Y	22 : R/Y
3 : R	13 : R/Y	23 : R/Y
4 : R	14 : R/Y	24 : R/W
5 : R/L	15 : R/Y	25 : —
6 : R/L	16 : R/Y	26 : —
7 : R	17 : R	27 : —
8 : R	18 : R	28 : —
9 : L/Y	19 : R/W	
10 : L/R	20 : R/W	